



# prplOS Network Functionality Test Plan

# Important notices, IPR statement, disclaimer and Copyright

This chapter contains important information about PRPL and this document (hereinafter 'This PRPL Document').

## **ABOUT PRPL**

The prpl Foundation (PRPL) is a not-for-profit organization which publishes documents including, but not limited to, Requirements, Specifications, Recommendations, API application programming interfaces, and Test Plans.

## **THIS MAY NOT BE THE LATEST VERSION OF THIS PRPL DOCUMENT**

This PRPL Document is the output of the Working Groups of the PRPL and its members as of the date of publication. Readers of This PRPL Document should be aware that it can be revised, edited or have its status changed according to the PRPL working procedures.

## **THERE IS NO WARRANTY PROVIDED WITH THIS PRPL DOCUMENT**

The services, the content and the information in This PRPL Document are provided on an "as is" basis. PRPL, to the fullest extent permitted by law, disclaims all warranties, whether express, implied, statutory or otherwise, including but not limited to the implied warranties of merchantability, non-infringement of third-parties rights and fitness for a particular purpose. PRPL, its affiliates and licensors make no representations or warranties about the accuracy, completeness, security or timeliness of the content or information provided in the PRPL Document. No information obtained via the PRPL Document shall create any warranty not expressly stated by PRPL in these terms and conditions.

## **EXCLUSION OF LIABILITY**

Any person holding a copyright in This PRPL Document, or any portion thereof, disclaims to the fullest extent permitted by law (a) any liability (including direct, indirect, special, or consequential damages under any legal theory) arising from or related to the use of or reliance upon This PRPL Document; and (b) any obligation to update or correct this technical report.

## **THIS PRPL DOCUMENT IS NOT BINDING ON PRPL NOR ITS MEMBER COMPANIES**

This PRPL Document, though formally approved by the PRPL member companies, is not binding in any way upon the PRPL members.

Patents essential or potentially essential to the implementation of features described in This PRPL

## INTELLECTUAL PROPERTY RIGHTS

Document may have been declared in conformance to the PRPL IP Policy (available at the PRPL website: [www.prplFoundation.org](http://www.prplFoundation.org)).

## COPYRIGHT PROVISIONS

This PRPL Document is copyrighted by PRPL, and all rights are reserved. The contents of This PRPL Document are protected by the copyrights of PRPL or the copyrights of third-parties that are used by agreement. Trademarks and copyrights mentioned in This PRPL Document are the property of their respective owners. The content of This PRPL Document may only be reproduced, distributed, modified, framed, cached, adapted or linked to, or made available in any form by any means, or incorporated into or used in any information storage and retrieval system, **with the prior written permission of PRPL or the applicable third-party copyright owner**. Such written permission is **not** however required under the conditions specified in the following two sections.

## INCORPORATING PRPL DOCUMENTS IN WHOLE OR PART WITHIN DOCUMENTS RELATED TO COMMERCIAL TENDERS

Any or all section(s) of PRPL Documents may be incorporated into Commercial Tenders (RFP, RFT, RFQ, ITT, etc.) by PRPL and non-PRPL members under the following conditions:

- (a) The PRPL Requirements numbers, where applicable, must not be changed from those within the PRPL Documents;
- (b) A prominent acknowledgement of the PRPL must be provided within the Commercial document identifying any and all PRPL Documents referenced and giving the web address of the PRPL;
- (c) The Commercial Tender must identify which of its section(s) include material taken from PRPL Documents and must identify each PRPL Document used, and the relevant PRPL Section Numbers; and,
- (d) The Commercial Tender must refer to the copyright provisions of PRPL Documents and must state that the sections taken from PRPL Documents are subject to copyright by PRPL and/or applicable third parties.

## COPYING THIS PRPL DOCUMENT IN ITS ENTIRETY

This PRPL Document may be electronically copied, reproduced, distributed, linked to, or made available by other means, or incorporated into or used in any information storage and retrieval system, but **only in its original, unaltered PDF format**, and with its original PRPL title and file name unaltered. It may not be modified without the advanced written permission of the PRPL

## Executive Summary

This prplOS Network Functionality test plan outlines the comprehensive validation strategy for prplOS's network-based functionality through its High-Level API implementation. The testing approach focuses on verifying the reliability, performance, and compliance of core networking components within the prplOS environment.

By leveraging the High-Level API, the test suite will validate both basic connectivity features and advanced networking capabilities across these components. This systematic approach ensures comprehensive coverage of essential networking services while verifying proper integration and interaction between different network functions.

Key objectives of this test plan include:

- Validation of network functionality through the High-Level API
- Verification of bridge configuration and operation
- Assessment of IP interface management and addressing
- Evaluation of DHCPv4 and DNS
- Testing of firewall rule effectiveness

This particular test plan is one component of a broader suite of test plans for formally Certifying implementations of “prplWare and High-Level API”.

The High-Level API, as an example, is a platform-agnostic API which is implemented on prpl-based platforms, but can also be implemented on others (e.g., platforms based on RDK or 3<sup>rd</sup>-party proprietary). Consequently, the test plan(s) for the High-Level API are specified in separate document(s) so that they remain platform-agnostic and hence applicable for other organizations.

There are separate test plans for the non-platform-agnostic aspects of the “prplWare and High-Level API” certification. For such certification tests, the goal is to discourage forking by verifying the authenticity and full realization of prplWare components underlying the High-Level API *in the specific implementation under test*.

This testing initiative will provide crucial validation of prplOS's networking capabilities, ensuring the platform meets its intended operational requirements.

## Revision History

Version	Date	Notes
1.2.0	10-December-2026	<ul style="list-style-type: none"> <li>● Added prplOS 4.1 mandatory tests:               <ul style="list-style-type: none"> <li>○ 1.2.10</li> <li>○ 1.2.25</li> <li>○ 1.2.27</li> <li>○ 1.2.28</li> <li>○ 1.3.7</li> <li>○ 1.4.2</li> <li>○ 1.4.3</li> <li>○ 1.4.4</li> <li>○ 1.5.4</li> <li>○ 1.5.5</li> <li>○ 1.5.6</li> <li>○ 1.5.7</li> <li>○ 1.5.14</li> <li>○ 1.5.15</li> <li>○ 1.5.16</li> <li>○ 1.5.17</li> </ul> </li> <li>● Added Provisional Excluded for prplOS 4.1:               <ul style="list-style-type: none"> <li>○ 1.2.19</li> </ul> </li> <li>● Fixed a text error in prplOS.1.1.6. [<a href="#">PCERT-107</a>]</li> </ul>
1.1.0	26-August-2025	<ul style="list-style-type: none"> <li>● Added prplOS 4.0 mandatory tests:               <ul style="list-style-type: none"> <li>○ 1.2.9</li> </ul> </li> </ul>

		<ul style="list-style-type: none"> <li>○ 1.2.26</li> <li>○ 1.2.29</li> <li>○ 1.4.6</li> <li>○ 1.4.9</li> <li>○ 1.5.1</li> <li>● Added Provisional Excluded for prplOS 4.0:           <ul style="list-style-type: none"> <li>○ 1.2.25</li> <li>○ 1.2.27</li> <li>○ 1.2.28</li> <li>○ 1.5.4 – 1.5.7</li> <li>○ 1.5.14 – 1.5.17</li> <li>○ 1.6.7 – 1.6.8</li> </ul> </li> <li>● Added DHCPv6 as mandatory and updated the Provisional Excluded list.</li> <li>● Updated prplOS.1.4.6 - prplOS.1.4.9 parameters to be Device.DNS.Relay.</li> <li>● Allow time for DHCPv6 lease to expire in prplOS.1.3.5 and prplOS.1.3.6.</li> <li>● Removed Router Advertisement verification in prplOS.1.6.19.</li> <li>● Removed IA_NA check from 1.3.15.</li> <li>● Updated 1.3.19 to use Vendor Specific Class</li> </ul>
--	--	---

		<p>Option.</p> <ul style="list-style-type: none"> <li>● Removed IA_PD check from 1.3.14</li> <li>● Updated 1.3.27 to use Vendor Class ID.</li> <li>● Updated 1.4.7 to find the WAN instance of DNS.Relay.Forwarding.</li> <li>● Added User Class ID to 1.3.9.</li> <li>● Updated 1.3.10 to use Vendor Specific Information Option.</li> </ul>
1.0.2	28-April-2025	<ul style="list-style-type: none"> <li>● Added support for prplOS 3.2.</li> <li>● Added Provisional Exclude and Optional to Core Features Table.</li> <li>● Removed Provisional Exclude tests from Optional Features</li> <li>● Updated alias reference in prplOS1.6.7.</li> <li>● Clarified USP and CWMP usage in Common Test Setup.</li> </ul>
1.0.1	22-Jan-2025	<ul style="list-style-type: none"> <li>● Added Core Features Table.</li> <li>● Added DNS Optional</li> </ul>

		<b>Features</b> <ul style="list-style-type: none"><li>○ prplOS.1.4.2</li><li>○ prplOS.1.4.3</li><li>○ prplOS.1.4.4</li><li>○ prplOS.1.4.6</li><li>○ prplOS.1.4.9</li><li>● Addressed inconsistencies in Functionality Tag and Option Feature Table.</li></ul>
1.0.0	14-Jan-2025	● Initial Release.

## Test Organization

This document organizes tests by group based on related test methodology or goals. Each group begins with a brief set of comments pertaining to all tests within that group. This is followed by a series of description blocks; each block describes a single test. The format of the description block is as follows:

<b>Test Label</b>	The Test Label and Title comprise the first line of the test block. The Test Label is composed of the short test suite name, the group number, and the test number within the group, separated by periods.
<b>Purpose</b>	The Purpose is a short statement describing what the test attempts to achieve. It is usually phrased as a simple assertion of the feature or capability to be tested.
<b>Reference</b>	The References section lists cross-references to the specifications and documentation that might be helpful in understanding and evaluating the test and results.
<b>Functionality Tag</b>	The functionality tag indicates whether the test is mandatory or optional as defined in prpl Certification Guide.
<b>Procedure</b>	The procedure indicates the steps, in order, taken to perform the test. Actions are steps taken by the test tool. Expected Behavior is what a device under test is required for passing the test.

# Table of Contents

Important notices, IPR statement, disclaimer and Copyright .....	2
Executive Summary .....	4
Revision History .....	5
Test Organization.....	9
Table of Contents.....	10
Results .....	14
Common Test Setup (CTS) .....	15
Topology .....	16
Provisional Excluded Tests.....	17
Group 1: Bridging.....	17
Group 2: DHCPv4.....	17
Group 3: DHCPv6.....	18
Group 4: DNS .....	18
Group 5: Firewall .....	19
Group 6: IP Interfaces.....	19
Optional Features .....	21
Section 1: Network Functionality.....	22
Group 1: Bridging .....	23
prplOS.1.1.1: Enable Bridge .....	24
prplOS.1.1.2: Enable Port.....	25
prplOS.1.1.3: Port LastChange.....	27
prplOS.1.1.4: Port BytesSent.....	28
prplOS.1.1.5: Port BytesReceived .....	29
prplOS.1.1.6: Port PacketsSent.....	30
prplOS.1.1.7: Port PacketsReceived .....	31
prplOS.1.1.8: Port UnicastPacketsSent.....	32
prplOS.1.1.9: Port UnicastPacketsReceived .....	33
prplOS.1.1.10: Port MulticastPacketsSent.....	34
prplOS.1.1.11: Port MulticastPacketsReceived .....	35
prplOS.1.1.12: Port BroadcastPacketsSent.....	36
prplOS.1.1.13: Port BroadcastPacketsReceived .....	37
Group 2: DHCPv4 .....	38
prplOS.1.2.1: DHCPv4 Client Status .....	39
prplOS.1.2.2: DHCPv4 Client DHCP Status .....	40
prplOS.1.2.3: DHCPv4 Client Reports Server Address .....	41
prplOS.1.2.4: DHCPv4 Client Reports DNS Server.....	42
prplOS.1.2.5: DHCPv4 Client Reports IP address.....	43
prplOS.1.2.6: DHCPv4 Client Reports IP Router.....	44
prplOS.1.2.7: DHCPv4 Client Reports Subnet Mask .....	45
prplOS.1.2.8: DHCPv4 Client Lease Time.....	46
prplOS.1.2.9: DHCPv4 Requested Option.....	47
prplOS.1.2.10: DHCPv4 Sent Option.....	49
prplOS.1.2.11: DHCPv4 Server Enabled.....	50
prplOS.1.2.12: DHCPv4 Server Pool Enabled.....	51
prplOS.1.2.13: DHCPv4 Server Pool Status.....	53
prplOS.1.2.14: DHCPv4 Server Reports Clients Active.....	54
prplOS.1.2.15: DHCPv4 Server Reports Address .....	55
prplOS.1.2.16: DHCPv4 Server Reports Address Lease .....	56

prpIOS.1.2.17: DHCPv4 Server Reports Options .....	58
prpIOS.1.2.18: DHCPv4 Server Lease .....	59
prpIOS.1.2.19: DHCPv4 Address Pool Size .....	60
prpIOS.1.2.20: DHCPv4 Address Assigned based on Hardware Address .....	62
prpIOS.1.2.21: DHCPv4 Address assignment based on Client ID .....	64
prpIOS.1.2.22: DHCPv4 Address assignment based on UserClass ID .....	66
prpIOS.1.2.23: DHCPv4 Address assignment based on VendorClass ID .....	68
prpIOS.1.2.24: DHCPv4 Address assignment based on Reserved .....	70
prpIOS.1.2.25: DHCPv4 Address assigns static address .....	71
prpIOS.1.2.26: DHCPv4 Server DNS Servers .....	73
prpIOS.1.2.27: DHCPv4 Server Domain Name .....	75
prpIOS.1.2.28: DHCPv4 Server Subnet Mask .....	76
prpIOS.1.2.29: DHCPv4 Server IPRouters .....	77
prpIOS.1.2.30: DHCPv4 Server Option .....	78
Group 3: DHCPv6 .....	80
prpIOS.1.3.1: DHCPv6 Client Status .....	81
prpIOS.1.3.2: DHCPv6 Client IA_NA .....	82
prpIOS.1.3.3: DHCPv6 Client IA_PD .....	84
prpIOS.1.3.4: DHCPv6 Client Rapid Commit.....	86
prpIOS.1.3.5: DHCPv6 Client Renew (T1 Timer) .....	88
prpIOS.1.3.6: DHCPv6 Client Rebind (T2 Timer) .....	90
prpIOS.1.3.7: DHCPv6 Client Requested Options.....	92
prpIOS.1.3.8: DHCPv6 Client Server Information .....	94
prpIOS.1.3.9: DHCPv6 Client Sent Options.....	95
prpIOS.1.3.10: DHCPv6 Client Received Options .....	96
prpIOS.1.3.11: Enable DHCPv6 Server .....	97
prpIOS.1.3.12: DHCPv6 Server Pool Enable.....	98
prpIOS.1.3.13: DHCPv6 Server Pool Status.....	99
prpIOS.1.3.14: Enable DHCPv6 Server IA_NA .....	100
prpIOS.1.3.15: Enable DHCPv6 Server IA_PD .....	102
prpIOS.1.3.16: DHCPv6 Server Report Clients Active. ....	103
prpIOS.1.3.17: DHCPv6 Server Report Clients Assigned Address .....	104
prpIOS.1.3.18: DHCPv6 Server Report Clients Assigned Prefixes.....	106
prpIOS.1.3.19: DHCPv6 Server Options.....	108
prpIOS.1.3.20: Manually Assign Address in DHCPv6 Pool .....	110
prpIOS.1.3.21: DHCPv6 Server IA_NA Address Available .....	111
prpIOS.1.3.22: Manually Assign Prefixes in DHCPv6 Pool .....	112
prpIOS.1.3.23: DHCPv6 Server IA_PD Address Available .....	113
prpIOS.1.3.24: DHCPv6 Assign information by DUID .....	114
prpIOS.1.3.25: DHCPv6 Assign information by Source Address.....	117
prpIOS.1.3.26: DHCPv6 Assign information by UserClassID .....	120
prpIOS.1.3.27: DHCPv6 Assign information by VendorClassID .....	123
Group 4: DNS.....	126
prpIOS.1.4.1: DNS Client Status.....	127
prpIOS.1.4.2: DNS Server from DHCPv4 .....	128
prpIOS.1.4.3: DNS Server from DHCPv6 .....	129
prpIOS.1.4.4: DNS Server from Router Advertisement .....	130
prpIOS.1.4.5: Static DNS .....	131
prpIOS.1.4.6: Enable DNS Proxy.....	132
prpIOS.1.4.7: DNS Proxy from DHCPv4.....	133
prpIOS.1.4.8: DNS Proxy from DHCPv6.....	134

prpIOS.1.4.9: DNS Proxy from Router Advertisement .....	135
Group 5: Firewall .....	136
prpIOS.1.5.1: Enable Firewall .....	137
prpIOS.1.5.2: Firewall LastChange .....	139
prpIOS.1.5.3: Default Policy .....	140
prpIOS.1.5.4: Enable Firewall Policies .....	141
prpIOS.1.5.5: Enable Firewall Chain .....	143
prpIOS.1.5.6: Enable Firewall Rules .....	145
prpIOS.1.5.7: Firewall Rules Protocol .....	148
prpIOS.1.5.8: Firewall Rules based on IP Version, IPv4 Policy .....	151
prpIOS.1.5.9: Firewall Rules based on IP Version, IPv6 Policy .....	153
prpIOS.1.5.10: Firewall Rules based on IPv4 Source Address .....	155
prpIOS.1.5.11: Firewall Rules based on IPv6 Source Address .....	157
prpIOS.1.5.12: Firewall Rules based on IPv4 Destination Address .....	160
prpIOS.1.5.13: Firewall Rules based on IPv6 Destination Address .....	162
prpIOS.1.5.14: Firewall Rules based on TCP Source Port .....	165
prpIOS.1.5.15: Firewall Rules based on UDP Source Port .....	168
prpIOS.1.5.16: Firewall Rules based on TCP Destination Port .....	170
prpIOS.1.5.17: Firewall Rules based on UDP Destination Port .....	173
prpIOS.1.5.18: Firewall Rules based on Source Mac .....	176
prpIOS.1.5.19: Firewall Rules based on DSCP .....	178
Group 6: IP Interfaces .....	181
prpIOS.1.6.1: IPv4 Status .....	182
prpIOS.1.6.2: IPv6 Status .....	183
prpIOS.1.6.3: IPv4 WAN Status .....	184
prpIOS.1.6.4: IPv6 WAN Status .....	185
prpIOS.1.6.5: IPv4 WAN Address .....	186
prpIOS.1.6.6: IPv6 Link Local WAN Address .....	187
prpIOS.1.6.7: IPv6 Global WAN Address .....	189
prpIOS.1.6.8: IPv6 WAN Router Advertisement Prefix .....	191
prpIOS.1.6.9: IPv6 WAN Prefix Delegation .....	193
prpIOS.1.6.10: IPv4 LAN Status .....	195
prpIOS.1.6.11: IPv6 LAN Status .....	196
prpIOS.1.6.12: IPv4 LAN Address .....	197
prpIOS.1.6.13: IPv6 Link Local LAN Address .....	198
prpIOS.1.6.14: IPv6 Global LAN Address .....	200
prpIOS.1.6.15: IPv6 LAN Prefix .....	202
prpIOS.1.6.16: IPv4 LAN Change Address .....	204
prpIOS.1.6.17: IPv4 LAN SubnetMask .....	205
prpIOS.1.6.18: IPv6 ULA .....	206
prpIOS.1.6.19: MTU Configuration .....	207
prpIOS.1.6.20: IP Interface BytesSent .....	208
prpIOS.1.6.21: IP Interface BytesReceived .....	209
prpIOS.1.6.22: IP Interface PacketsSent .....	210
prpIOS.1.6.23: IP Interface PacketsReceived .....	211
prpIOS.1.6.24: IP Interface UnicastPacketsSent .....	212
prpIOS.1.6.25: IP Interface UnicastPacketsReceived .....	213
prpIOS.1.6.26: IP Interface MulticastPacketsSent .....	214
prpIOS.1.6.27: IP Interface MulticastPacketsReceived .....	215
prpIOS.1.6.28: IP Interface BroadcastPacketsSent .....	216
prpIOS.1.6.29: IP Interface BroadcastPacketsReceived .....	217



References.....218

## Results


Each test in the prplOS Test Plan must have a pass and fail metric, per Section 5.2 of the [prpl Certification Program Guide](#).

## Common Test Setup (CTS)

A DUT is provisioned with the following:

1. IPv4 addresses on both the WAN and LAN interfaces
2. IPv6 addresses on both the WAN and LAN interfaces.
3. WAN interfaces are using DHCPv6 and DHCPv4 to acquire addresses.
4. The following Servers are configured on the DUT.
  - a. DNS
  - b. NTP
5. USP is configured to allow management of the DUT
  - a. USP is required for **prplWare and HL-API Certification**.
  - b. To demonstrate CWMP support, an optional feature in the HL-API Test Plan, each test must additionally be executed with CWMP as the protocol.

# Topology



## Provisional Excluded Tests

The subsequent table presents a comprehensive list of all test cases. Notably, certain test cases have uncovered issues that are currently undergoing resolution as part of prplOS maintenance. Tests designated with 'PE' are provisionally excluded from the current testing cycle, pending the release of a corrective patch in a future release of prplOS. Conversely, test cases marked with 'X' are mandatory for achieving prplWare certification for this particular version. Test cases marked with 'O' are optional features.

### Group 1: Bridging

Test	prplWare 3.1	prplWare 3.2	prplWare 4.0	prplWare 4.1
prplOS.1.1.1	O	O	O	O
prplOS.1.1.2	O	O	O	O
prplOS.1.1.3	X	X	X	X
prplOS.1.1.4	X	X	X	X
prplOS.1.1.5	X	X	X	X
prplOS.1.1.6	X	X	X	X
prplOS.1.1.7	X	X	X	X
prplOS.1.1.8	PE	PE	PE	PE
prplOS.1.1.9	PE	PE	PE	PE
prplOS.1.1.10	PE	PE	PE	PE
prplOS.1.1.11	PE	PE	PE	PE
prplOS.1.1.12	PE	PE	PE	PE
prplOS.1.1.13	PE	PE	PE	PE

### Group 2: DHCPv4

Test	prplWare 3.1	prplWare 3.2	prplWare 4.0	prplWare 4.1
prplOS.1.2.1	X	X	X	X
prplOS.1.2.2	X	X	X	X
prplOS.1.2.3	X	X	X	X
prplOS.1.2.4	X	X	X	X
prplOS.1.2.5	X	X	X	X
prplOS.1.2.6	X	X	X	X
prplOS.1.2.7	X	X	X	X
prplOS.1.2.8	X	X	X	X
prplOS.1.2.9	PE	PE	X	X
prplOS.1.2.10	PE	PE	PE	X
prplOS.1.2.11	X	X	X	X
prplOS.1.2.12	X	X	X	X
prplOS.1.2.13	X	X	X	X
prplOS.1.2.14	X	X	X	X
prplOS.1.2.15	X	X	X	X
prplOS.1.2.16	X	X	X	X
prplOS.1.2.17	X	X	X	X
prplOS.1.2.18	X	X	X	X
prplOS.1.2.19	X	X	X	PE
prplOS.1.2.20	PE	PE	PE	PE

prplOS.1.2.21	PE	PE	PE	PE
prplOS.1.2.22	PE	PE	PE	PE
prplOS.1.2.23	PE	PE	PE	PE
prplOS.1.2.24	PE	PE	PE	PE
prplOS.1.2.25	X	X	PE	X
prplOS.1.2.26	PE	PE	X	X
prplOS.1.2.27	X	X	PE	X
prplOS.1.2.28	X	X	PE	X
prplOS.1.2.29	PE	PE	X	X
prplOS.1.2.30	PE	PE	PE	PE

### Group 3: DHCPv6

Test	prplWare 3.1	prplWare 3.2	prplWare 4.0	prplWare 4.1
prplOS.1.3.1	O	O	X	X
prplOS.1.3.2	O	O	X	X
prplOS.1.3.3	O	O	X	X
prplOS.1.3.4	O	O	PE	PE
prplOS.1.3.5	O	O	PE	PE
prplOS.1.3.6	O	O	PE	PE
prplOS.1.3.7	O	O	PE	X
prplOS.1.3.8	O	O	X	X
prplOS.1.3.9	O	O	PE	PE
prplOS.1.3.10	O	O	X	X
prplOS.1.3.11	O	O	PE	PE
prplOS.1.3.12	O	O	X	X
prplOS.1.3.13	O	O	X	X
prplOS.1.3.14	O	O	PE	PE
prplOS.1.3.15	O	O	O	O
prplOS.1.3.16	O	O	PE	PE
prplOS.1.3.17	O	O	X	X
prplOS.1.3.18	O	O	PE	PE
prplOS.1.3.19	O	O	PE	PE
prplOS.1.3.20	O	O	PE	PE
prplOS.1.3.21	O	O	PE	PE
prplOS.1.3.22	O	O	PE	PE
prplOS.1.3.23	O	O	PE	PE
prplOS.1.3.24	O	O	PE	PE
prplOS.1.3.25	O	O	PE	PE
prplOS.1.3.26	O	O	PE	PE
prplOS.1.3.27	O	O	PE	PE

### Group 4: DNS

Test	prplWare 3.1	prplWare 3.2	prplWare 4.0	prplWare 4.1
prplOS.1.4.1	X	X	X	X
prplOS.1.4.2	PE	PE	PE	X
prplOS.1.4.3	PE	PE	PE	X

prplOS.1.4.4	PE	PE	PE	X
prplOS.1.4.5	X	X	X	X
prplOS.1.4.6	PE	PE	X	X
prplOS.1.4.7	X	X	X	X
prplOS.1.4.8	X	X	X	X
prplOS.1.4.9	PE	PE	X	X

### Group 5: Firewall

Test	prplWare 3.1	prplWare 3.2	prplWare 4.0	prplWare 4.1
prplOS.1.5.1	PE	PE	X	X
prplOS.1.5.2	X	X	X	X
prplOS.1.5.3	X	X	X	X
prplOS.1.5.4	X	X	PE	X
prplOS.1.5.5	X	X	PE	X
prplOS.1.5.6	X	X	PE	X
prplOS.1.5.7	X	X	PE	X
prplOS.1.5.8	X	X	X	X
prplOS.1.5.9	X	X	X	X
prplOS.1.5.10	X	X	X	X
prplOS.1.5.11	X	X	X	X
prplOS.1.5.12	X	X	X	X
prplOS.1.5.13	X	X	X	X
prplOS.1.5.14	X	X	PE	X
prplOS.1.5.15	X	X	PE	X
prplOS.1.5.16	X	X	PE	X
prplOS.1.5.17	X	X	PE	X
prplOS.1.5.18	PE	PE	PE	PE
prplOS.1.5.19	PE	PE	PE	PE

### Group 6: IP Interfaces

Test	prplWare 3.1	prplWare 3.2	prplWare 4.0	prplWare 4.1
prplOS.1.6.1	PE	PE	PE	PE
prplOS.1.6.2	PE	PE	PE	PE
prplOS.1.6.3	X	X	X	X
prplOS.1.6.4	X	X	X	X
prplOS.1.6.5	X	X	X	X
prplOS.1.6.6	PE	PE	PE	PE
prplOS.1.6.7	X	X	PE	PE
prplOS.1.6.8	X	X	PE	PE
prplOS.1.6.9	X	X	X	X
prplOS.1.6.10	X	X	X	X
prplOS.1.6.11	X	X	X	X
prplOS.1.6.12	X	X	X	X
prplOS.1.6.13	PE	PE	PE	PE
prplOS.1.6.14	X	X	X	X
prplOS.1.6.15	PE	PE	PE	PE
prplOS.1.6.16	X	X	X	X

prplOS.1.6.17	X	X	X	X
prplOS.1.6.18	X	X	X	X
prplOS.1.6.19	PE	PE	PE	PE
prplOS.1.6.20	X	X	X	X
prplOS.1.6.21	X	X	X	X
prplOS.1.6.22	X	X	X	X
prplOS.1.6.23	X	X	X	X
prplOS.1.6.24	PE	PE	PE	PE
prplOS.1.6.25	PE	PE	PE	PE
prplOS.1.6.26	PE	PE	PE	PE
prplOS.1.6.27	PE	PE	PE	PE
prplOS.1.6.28	PE	PE	PE	PE
prplOS.1.6.29	PE	PE	PE	PE

## Optional Features

This is the list of optional features and the associated test cases.

- Multiple Ethernet LAN Ports
  - prplOS.1.1.1 – prplOS.1.1.2
- DHCPv6 Prefix Delegation
  - prplOS.1.3.15
- CWMP
  - Execute all the tests using CMWP.

# Section 1: Network Functionality

## Overview

The following tests verify network functionality of a DUT. USP or CWMP can be utilized for management of the DUT during the test. The objects and parameters tested in this section are available in both the USP and CWMP versions of the HL-API Data Model.

## Group 1: Bridging

### Scope

The following test covers bridging and vlan support of a prplOS implementation.

### Overview

The tests in this group verify the DUT properly implements basic ethernet, vlans, and bridge configurations and statics.

## prplOS.1.1.1: Enable Bridge

**Purpose:** Verify that bridges can be enabled and disabled.

**Parameters:**

Device.Bridging.Bridge.<LAN>.	
Enable	true
Status	Enable

**Functionality Tags:** Multiple Ethernet LAN Ports

**Test Setup:** Common Test Setup is used at the beginning of each part. Client-1 is attached to first Ethernet port on the DUT, labeled LAN1. LAN1 is a label that may be changed based on the alias in the data model. Each Client is attached to a different interface.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.Bridging.Bridge.<LAN>.Enable=false.	
2.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN_Bridge>.Status	The DUT must return a value of Disabled for the parameter.
3.	Transmit traffic from Client-1 to Client-2.	The DUT must not forward traffic from Client-1 to Client-2.
4.	Set the parameter Device.Bridging.Bridge.<LAN>.Enable=true.	
5.	Get the parameter Device.Bridging.Bridge.<LAN>.Status	The DUT must return a value of Enabled for the parameter.
6.	Transmit traffic from Client-1 to Client-2.	The DUT must not forward traffic from Client-1 to Client-2.

## prplOS.1.1.2: Enable Port

**Purpose:** Verify that ports can be enabled and disabled.

**Parameters:**

Device.Bridging.Bridge.<LAN>.Port.<LAN1>.	
Enable	true
Status	

**Functionality Tags:** Multiple Ethernet LAN Ports

**Test Setup:** Common Test Setup is used at the beginning of each part. Client-1 is attached to first Ethernet port on the DUT, labeled LAN1. LAN1 is a label that may be changed based on the alias in the data model. Each Client is attached to a different interface.

**Procedure:**

Step	Action	Expected Behavior
1.	Transmit traffic from Client-2 to Client-1.	The DUT must forward traffic from Client-2 to Client-1.
2.	Set the parameter Device.Bridging.Bridge. <LAN>.Port.<LAN1>.Enable=false.	
3.	Get the parameter Device.Bridging.Bridge. <LAN>.Port.<LAN1>.Status	The DUT must return a value of DOWN for the parameter.
4.	Transmit traffic from Client-2 to Client-1.	The DUT must not forward traffic from Client-2 to Client-1.
5.	Transmit traffic from Client-2 to Host-1.	The DUT must forward traffic from Client-2 to Host-1.
6.	Set the parameter Device.Bridging.Bridge. <LAN>.Port.<LAN1>.Enable=true.	
7.	Get the parameter Device.Bridging.Bridge. <LAN>.Port.<LAN1>.Status	The DUT must return a value of UP for the parameter.

8.	Transmit traffic from Client-2 to Client-1.	The DUT must forward traffic from Client-2 to Client-1.
9.	Transmit traffic from Client-2 to Host-1.	The DUT must forward traffic from Client-2 to Host-1.

### prplOS.1.1.3: Port LastChange

**Purpose:** Verify that LastChange parameter is properly implemented in the Port object.

**Parameters:**

Device.Bridging.Bridge.<LAN>.Port.<LAN1>	
Enable	true
LastChange	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part. Client-1 is attached to first Ethernet port on the DUT, labeled LAN1. LAN1 is a label that may be changed based on the alias in the data model.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.Bridging.Bridge. <LAN>.Port.<LAN1>.LastChange	The DUT returns a value in seconds since the last operational state change.
2.	Set the parameter Device.Bridging.Bridge. <LAN>.Port.<LAN1>.Enable=false.	
3.	Get the parameter Device.Bridging.Bridge. <LAN>.Port.<LAN1>.LastChange	The DUT returns a value in seconds that is less than the value in Step 1.

## prplOS.1.1.4: Port BytesSent

**Purpose:** Verify that the statistics for Port.{i}.Stats.BytesSent are properly reported.

**Parameters:**

Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.	
BytesSent	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part. Client-1 is attached to first Ethernet port on the DUT, labeled LAN1. LAN1 is a label that may be changed based on the alias in the data model.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.BytesSent	The DUT returns the value of BytesSent.
2.	Transmit ICMP Request that is 500 bytes of data from Client-1 to Host-1.	Host-1 transmits an Echo Reply to Client-1.
3.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.BytesSent	The DUT returns a value of BytesSent that is 500 bytes more than the value in Step 1.

## prplOS.1.1.5: Port BytesReceived

**Purpose:** Verify that the statistics for Port.{i}.Stats.BytesReceived are properly reported.

**Parameters:**

Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.	
BytesReceived	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part. Client-1 is attached to first Ethernet port on the DUT, labeled LAN1. LAN1 is a label that may be changed based on the alias in the data model.

**Procedure:**

Step	Action	Expected Behavior
1.	Transmit traffic from Client-1 to Host-1.	The DUT must forward traffic from Client-1 to Host-1.
2.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.BytesReceived	The DUT returns the value of BytesReceived.
3.	Transmit 500 bytes of data from Client-1 to Host-1.	
4.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.BytesReceived	The DUT returns a value of BytesReceived that is 500 bytes more than the value in Step 1.

## prplOS.1.1.6: Port PacketsSent

**Purpose:** Verify that the statistics for the Port. $\{i\}$ .Stats.PacketsSent are properly reported.

**Parameters:**

Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.	
PacketsSent	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part. Client-1 is attached to first Ethernet port on the DUT, labeled LAN1. LAN1 is a label that may be changed based on the alias in the data model.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.PacketsSent	The DUT returns the value of PacketsSent.
2.	Transmit 5 ICMP Request from Client-1 to Host-1.	Host-1 transmits an Echo Reply to Client-1.
3.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.PacketsSent	The DUT returns a value of PacketsSent that is 5 packets more than the value in Step 1.

## prplOS.1.1.7: Port PacketsReceived

**Purpose:** Verify that the statistics for the Port.{i}.Stats.PacketsReceived are properly reported.

**Parameters:**

Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.	
PacketsReceived	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part. Client-1 is attached to first Ethernet port on the DUT, labeled LAN1. LAN1 is a label that may be changed based on the alias in the data model.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.PacketsReceived	The DUT returns the value of PacketsReceived.
2.	Transmit 5 packets from Client-1 to Host-1.	
3.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.PacketsReceived	The DUT returns a value of PacketsReceived that is 5 packets more than the value in Step 1.

## prplOS.1.1.8: Port UnicastPacketsSent

**Purpose:** Verify that the statistics for the Port.{i}.Stats.UnicastPacketsSent are properly reported.

**Parameters:**

Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.	
UnicastPacketsSent	

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part. Client-1 is attached to first Ethernet port on the DUT, labeled LAN1. LAN1 is a label that may be changed based on the alias in the data model.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.UnicastPacketsSent	The DUT returns the value of UnicastPacketsSent.
2.	Transmit 5 unicast packets from Client-1 to the DUT.	The DUT transmits unicast packets in response.
3.	Transmit 5 multicast packets from Client-1 to the DUT.	The DUT transmits multicast packets in response.
4.	Transmit 5 broadcast packets from Client-2 to the DUT.	The DUT transmits broadcast packets in response.
5.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.UnicastPacketsSent	The DUT returns a value of UnicastPacketsSent that is 5 packets more than the value in Step 1.

## prplOS.1.1.9: Port UnicastPacketsReceived

**Purpose:** Verify that the statistics for the Port.{i}.Stats.UnicastPacketsReceived are properly reported.

**Parameters:**

Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.	
UnicastPacketsReceived	

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part. Client-1 is attached to first Ethernet port on the DUT, labeled LAN1. LAN1 is a label that may be changed based on the alias in the data model.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.UnicastPacketsReceived	The DUT returns the value of UnicastPacketsReceived.
2.	Transmit 5 unicast packets from Client-1 to the DUT.	
3.	Transmit 5 multicast packets from Client-1 to the DUT.	
4.	Transmit 5 broadcast packets from Client-1 to the DUT.	
5.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.UnicastPacketsReceived.	The DUT returns a value of UnicastPacketsReceived that is 5 packets more than the value in Step 1.

## prplOS.1.1.10: Port MulticastPacketsSent

**Purpose:** Verify that the statistics for the Port.{i}.Stats.MulticastPacketsSent are properly reported.

**Parameters:**

Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.	
MulticastPacketsSent	

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part. Client-1 is attached to first Ethernet port on the DUT, labeled LAN1. LAN1 is a label that may be changed based on the alias in the data model.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.MulticastPacketsSent	The DUT returns the value of MulticastPacketsSent.
2.	Transmit 5 unicast packets from Client-1 to the DUT.	The DUT transmits unicast packets in response.
3.	Transmit 5 multicast packets from Client-1 to the DUT.	The DUT transmits multicast packets in response.
4.	Transmit 5 broadcast packets from Client-1 to the DUT.	The DUT transmits broadcast packets in response.
5.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.MulticastPacketsSent	The DUT returns a value of MulticastPacketsSent that is 5 packets more than the value in Step 1.

## prplOS.1.1.11: Port MulticastPacketsReceived

**Purpose:** Verify that the statistics for the Port.{i}.Stats.MulticastPacketsReceived are properly reported.

**Parameters:**

Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.	
MulticastPacketsReceived	

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part. Client-1 is attached to first Ethernet port on the DUT, labeled LAN1. LAN1 is a label that may be changed based on the alias in the data model.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.MulticastPacketsReceived	The DUT returns the value of MulticastPacketsReceived.
2.	Transmit 5 unicast packets from Client-1 to the DUT.	
3.	Transmit 5 multicast packets from Client-2 to the DUT.	
4.	Transmit 5 broadcast packets from Client-2 to the DUT.	
5.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.MulticastPacketsReceived	The DUT returns a value of MulticastPacketsReceived that is 5 packets more than the value in Step 1.

## prplOS.1.1.12: Port BroadcastPacketsSent

**Purpose:** Verify that the statistics for the Port.`{i}`.Stats.BroadcastPacketsSent are properly reported.

**Parameters:**

Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.	
BroadcastPacketsSent	

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part. Client-1 is attached to first Ethernet port on the DUT, labeled LAN1. LAN1 is a label that may be changed based on the alias in the data model.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.BroadcastPacketsSent	The DUT returns the value of BroadcastPacketsSent.
2.	Transmit 5 unicast packets from Client-1 to the DUT.	The DUT transmits unicast packets in response.
3.	Transmit 5 multicast packets from Client-1 to the DUT.	The DUT transmits multicast packets in response.
4.	Transmit 5 broadcast packets from Client-1 to the DUT.	The DUT transmits broadcast packets in response.
5.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.BroadcastPacketsSent	The DUT returns a value of BroadcastPacketsSent that is 5 packets more than the value in Step 1.

### prplOS.1.1.13: Port BroadcastPacketsReceived

**Purpose:** Verify that the statistics for the Port.{i}.Stats.BroadcastPacketsReceived are properly reported.

**Parameters:**

Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.	
BroadcastPacketsReceived	

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part. Client-1 is attached to first Ethernet port on the DUT, labeled LAN1. LAN1 is a label that may be changed based on the alias in the data model.

**Procedure:**

Step	Action	Expected Behavior
1.	Transmit traffic from Client-1 to Client-2.	The DUT must forward traffic from Client-1 to Client-2.
2.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.BroadcastPacketsReceived	The DUT returns the value of BroadcastPacketsReceived.
3.	Transmit 5 unicast packets from Client-2 to Client-1.	
4.	Transmit 5 multicast packets from Client-2 to Client-1.	
5.	Transmit 5 broadcast packets from Client-2 to Client-1.	
6.	Get the parameter Device.Bridging.Bridge.<LAN>.Port.<LAN1>.Stats.BroadcastPacketsReceived	The DUT returns a value of BroadcastPacketsReceived that is 5 packets more than the value in Step 1.

## Group 2: DHCPv4

### Scope

The following test covers DHCPv4 support of a prplOS implementations.

### Overview

The tests in this group verify the DUT properly implements DHCPv4 configuration for both WAN and LAN interface.

## prplOS.1.2.1: DHCPv4 Client Status

**Purpose:** Ensure the status of the DHCPv4 Client can be verified.

**Parameters:**

Device.DHCPv4.Client	
Enable	true
Interface	<WAN>

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.DHCPv4.Client.<WAN>.Status	The value returned from the DUT must be "Enabled".

## prplOS.1.2.2: DHCPv4 Client DHCP Status

**Purpose:** Ensure the DHCP status of the DHCPv4 Client can be verified.

**Parameters:**

Device.DHCPv4.Client	
Enable	true
Interface	<WAN>

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.DHCPv4.Client.<WAN>.DHCPStatus.	The value returned from the DUT must be "Bound".
2.	Disable the DHCP Server.	
3.	Wait for DUT to enter the Renewing state.	The DUT must transmit a DHCPREQUEST message to DHCP-Server.
4.	Get the parameter Device.DHCPv4.Client.<WAN>.DHCPStatus.	The value returned from the DUT must be "Renewing".
5.	Wait for the DUT to enter the Rebind state.	The DUT must transmit a broadcast DHCPREQUEST message.
6.	Get the parameter Device.DHCPv4.Client.<WAN>.DHCPStatus.	The value returned from the DUT must be "Rebinding".
7.	Enable the DHCP Server.	The DUT must complete the DHCP exchange with the Server.
8.	Get the parameter Device.DHCPv4.Client.<WAN>.DHCPStatus	The value returned from the DUT must be "Bound".

### prplOS.1.2.3: DHCPv4 Client Reports Server Address

**Purpose:** Verify that the DHCPv4 Client reports the server address.

**Parameters:**

Device.DHCPv4.Client	
Enable	true
Interface	<WAN>

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.DHCPv4.Client.<WAN>.DHCP Server	The IPv4 source address of the DHCP Server must be returned.

### prplOS.1.2.4: DHCPv4 Client Reports DNS Server

**Purpose:** Verify that the DHCPv4 Client reports the DNS Server.

**Parameters:**

Device.DHCPv4.Client	
Enable	true
Interface	WAN Interface

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.DHCPv4.Client.<WAN>.DNS Servers	The DUT must return a value of IPv4 address of the DNS-Server-1.

prplOS.1.2.5: DHCPv4 Client Reports IP address

**Purpose:** Verify that the DHCPv4 Client reports the IP address assigned by the DHCP Server.

**Parameters:**

Device.DHCPv4.Client	
Enable	true
Interface	WAN Interface

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.DHCPv4.Client.<WAN>.IPAd dress	The DUT must return a value of IPv4 address assigned during common test setup.

## prplOS.1.2.6: DHCPv4 Client Reports IP Router

**Purpose:** Verify that the DHCPv4 Client reports the IP router assigned by the DHCP Server.

**Parameters:**

Device.DHCPv4.Client	
Enable	true
Interface	WAN Interface

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.DHCPv4.Client.<WAN>.IPRouters.	The DUT must return a value of IPv4 address of the IP Router assigned in the common test setup.

## prplOS.1.2.7: DHCPv4 Client Reports Subnet Mask

**Purpose:** Verify that the DHCPv4 Client reports the subnet mask assigned by the DHCP Server.

**Parameters:**

Device.DHCPv4.Client	
Enable	true
Interface	WAN Interface

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.DHCPv4.Client.<WAN>.SubnetMask.	The DUT must return a value of IPv4 address of the subnet mask assigned in the common test setup.

## prplOS.1.2.8: DHCPv4 Client Lease Time

**Purpose:** Verify that the DHCPv4 Client reports the lease time.

**Parameters:**

Device.DHCPv4.Client	
Enable	true
Interface	WAN Interface

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Wait for the DHCP Request from the DUT to the DHCP Server.	The DHCP Server transmits a DHCPACK with an IP address lease time of 100 seconds.
2.	Allow time for the DUT to process the DHCP message.	
3.	Get the parameter Device.DHCPv4.Client.<WAN>.LeaseTimeRemaining.	The DUT must return a value of less than 100 seconds.
4.	Wait for the DHCP Request from the DUT to the DHCP Server.	The DHCP Server transmits a DHCPACK with an IP address lease time of 150 seconds.
5.	Allow time for the DUT to process the DHCP message.	
6.	Get the parameter Device.DHCPv4.Client.<WAN>.LeaseTimeRemaining.	The DUT must return a value of less than 150 seconds.

## prplOS.1.2.9: DHCPv4 Requested Option

**Purpose:** Verify that the DHCPv4 Client reports the requested DHCP Options.

**Parameters:**

Device.DHCPv4.Client.<WAN>.ReqOption.<i>	
Enable	true
Tag	43

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv4.Client.<WAN>.ReqOption.<ReqOption Instance>.Enable=false.	
2.	Disable the DHCP Server.	
3.	Wait 80 seconds.	The DUT transmits a DHCPDISCOVER message that does not request the Vendor-Specific Information option in the Parameter Request List.
4.	Enable the DHCP Server.	The DUT must complete the DHCP exchange with the Server.
5.	Set the parameter Device.DHCPv4.Client.<WAN>.ReqOption.<ReqOption Instance>.Enable=true.	
6.	Disable the DHCP Server.	
7.	Wait 80 seconds.	The DUT transmits a DHCPDISCOVER message with a Vendor-Specific Information option included in the Parameter Request List.



## prplOS.1.2.10: DHCPv4 Sent Option

**Purpose:** Verify that the DHCPv4 Client reports the sent DHCP Options.

**Parameters:**

Device.DHCPv4.Client.<WAN>.SentOption.<i>.	
Enable	true
Tag	60
Value	

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv4.Client.<WAN>.SentOption.<SentOption Instance>.Value=7072706C20.	
2.	Disable the DHCP Server.	
3.	Wait 80 seconds.	The DUT transmits a DHCPREQUEST message with a Vendor Class Identifier option included with value of "dhcp".
4.	Enable the DHCP Server.	The DUT must complete the DHCP exchange with the Server.
5.	Set the parameter Device.DHCPv4.Client.<WAN>.SentOption.<SentOption Instance>.Enable=false.	
6.	Disable the DHCP Server.	
7.	Wait 80 seconds.	The DUT transmits a DHCPREQUEST message that does not include the Vendor Class Identifier option.

### prpIOS.1.2.11: DHCPv4 Server Enabled

**Purpose:** Verify that the DHCPv4 Server can be enabled and disabled.

**Parameters:**

Device.DHCPv4.Server	
Enable	true

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv4.Server.Enable=false.	
2.	Allow time for the DUT to process the set.	
3.	Transmit a DHCPDISCOVER message from Client-1.	Ensure the DUT does not transmit any DHCPv4 message in response to the DHCPDISCOVER.
4.	Set the parameter Device.DHCPv4.Server.Enable=true.	
5.	Allow time for the DUT to process the set.	
6.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCPOFFER in response to the DHCPDISCOVER.
7.	Transmit a DHCPREQUEST message from Client-1.	The DUT must transmit a DHCPACK in response to the DHCPREQUEST.

## prplOS.1.2.12: DHCPv4 Server Pool Enabled

**Purpose:** Verify the DHCPv4 Server pool can be enabled and disabled.

**Parameters:**

Device.DHCPv4.Server.Pool.<LAN>.	
Enable	true
MaxAddress	<Max Address in range on LAN>
MinAddress	<Min Address in range on LAN>
SubnetMask	255.255.255.0

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>. Enable=false.	
2.	Allow time for the DUT to process the set.	
3.	Transmit a DHCPDISCOVER message from Client-1.	Ensure the DUT does not transmit any DHCPv6 message on the LAN interface.
4.	Set the parameter Device.DHCPv6.Server.Pool.<LAN>. Enable=true.	
5.	Allow time for the DUT to process the set.	
6.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCPOFFER in response to the DHCPDISCOVER.
7.	Transmit a DHCPREQUEST message from Client-1.	The DUT must transmit a DHCPACK in response to the DHCPREQUEST.



## prplOS.1.2.13: DHCPv4 Server Pool Status

**Purpose:** Verify the DHCPv4 Server pool status.

**Parameters:**

Device.DHCPv4.Server.Pool.<LAN>.	
Enable	true

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>. Enable=false.	
2.	Allow time for the DUT to process the set.	
3.	Get the parameter Device.DHCPv4.Server.Pool.<LAN>. Status	The value returned from the DUT must be "Disabled".
4.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>. Enable=true.	Ensure the DUT does not transmit any DHCPv4 message on the LAN interface.
5.	Allow time for the DUT to process the set.	
6.	Get the parameter Device.DHCPv4.Server.Pool.<LAN>. Status	The value returned from the DUT must be "Enabled".

## prplOS.1.2.14: DHCPv4 Server Reports Clients Active

**Purpose:** Ensure DHCPv4 Server reports if a DHCPv4 Client is present on the LAN.

**Parameters:**

Device.DHCPv4.Server.Pool.<LAN>.	
Enable	true
AllowDevices	All

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCP OFFER to Client-1 offering a valid IPv4 address assignment.
2.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 containing a valid IPv4 address.
3.	Get the parameter Device.DHCPv4.Server.Pool.<LAN>.Client.<Client-1>.Chaddr	The DUT must return the value of the MAC address of Client-1.
4.	Get the parameter Device.DHCPv4.Server.Pool.<LAN>.Client.<Client-1>.Active	The DUT must return a value of true.

## prplOS.1.2.15: DHCPv4 Server Reports Address

**Purpose:** Ensure DHCPv4 Server reports addresses assigned using DHCP.

**Parameters:**

Device.DHCPv4.Server.Pool.<LAN>.	
Enable	true
AllowDevices	All
MaxAddress	<Max Address in range on LAN>
MinAddress	<Min Address in range on LAN>

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCPOFFER to Client-1 offering a valid IPv4 address assignment.
2.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 containing a valid IPv4 address.
3.	Get the parameter Device.DHCPv4.Server.Pool.<LAN>. Client.<Client-1>.IPv4Address.1.IPAddress.	The DUT must return the value of the IPv4 address assigned in Step 2.

## prpIOS.1.2.16: DHCPv4 Server Reports Address Lease

**Purpose:** Ensure DHCPv4 Server reports addresses lease time assigned.

**Parameters:**

Device.DHCPv4.Server.Pool.<LAN>.	
Enable	true
AllowDevices	All
MaxAddress	<Max Address in range on LAN>
MinAddress	<Min Address in range on LAN>

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>. LeaseTime=150.	
2.	Allow time for the DUT to process the set.	
3.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCP OFFER to Client-1 offering a valid IPv4 address assignment.
4.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 containing a valid IPv4 address and lease time of 150 seconds.
5.	Get the parameter Device.DHCPv4.Server.Pool.<LAN>. Client.<Client-1>.IPv4Address.1.LeaseTimeRemaining.	The DUT must return a time less than 80 seconds in the future.
6.	Wait T1 to transmit DHCPREQUEST to the DUT.	The DUT must transmit a DHCPACK.

7.	Get the parameter Device.DHCPv4.Server.Pool.<LAN>. Client.<Client- 1>.IPv4Address.1.LeaseTimeRemaini ng.	The DUT must return a time that is more than T1 seconds in the future.
----	--	---

## prplOS.1.2.17: DHCPv4 Server Reports Options

**Purpose:** Ensure DHCPv4 Server reports options sent by the clients on LAN.

**Parameters:**

Device.DHCPv4.Server.Pool.<LAN>.	
Enable	true
AllowDevices	All
MaxAddress	<Max Address in range on LAN>
MinAddress	<Min Address in range on LAN>

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Transmit a DHCPDISCOVER message from Client-1 containing a VendorClassID option.	The DUT must transmit a DHCPOFFER.
2.	Transmit a DHCPREQUEST message from Client-1 to the DUT containing a VendorClassID option.	The DUT must transmit a DHCPACK to Client-1.
3.	Get all the objects in the path Device.DHCPv4.Server.Pool.<LAN>. Client.<Client-1>Option.	The DUT must return an Object that contains VendorClassID.

## prplOS.1.2.18: DHCPv4 Server Lease

**Purpose:** Ensure DHCPv4 Server assigns the lease time.

**Parameters:**

Device.DHCPv4.Server.Pool.<LAN>.	
Enable	true
AllowDevices	All
MaxAddress	<Max Address in range on LAN>
MinAddress	<Min Address in range on LAN>

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>. LeaseTime=80.	
2.	Allow time for the DUT to process the set.	
3.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCP OFFER.
4.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 with a lease time set to 80 seconds.

## prplOS.1.2.19: DHCPv4 Address Pool Size

**Purpose:** Ensure DHCPv4 Server properly assigns addresses in the pool.

**Parameters:**

Device.DHCPv4.Server.Pool.<LAN>.	
Enable	true
AllowDevices	All

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part. Determine the existing DHCPv4 Pool size. The pool size must be greater than 3 addresses to run this test.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameters Device.DHCPv4.Server.Pool.<LAN>. MinAddress and Device.DHCPv4.Server.Pool.<LAN>. MaxAddress so that the pool contains 3 addresses.	
2.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCPOFFER.
3.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 with an address in the configured pool.
4.	Transmit a DHCPDISCOVER message from Client-2.	The DUT must transmit a DHCPOFFER.
5.	Transmit a DHCPREQUEST message from Client-2 to the DUT.	The DUT must transmit a DHCPACK to Client-3 with an address in the configured pool.
6.	Transmit a DHCPDISCOVER message from Client-3.	The DUT must transmit a DHCPOFFER.
7.	Transmit a DHCPREQUEST message from Client-3 to the DUT.	The DUT must transmit a DHCPACK to Client-3 with an address in the

		configured pool.
8.	Transmit a DHCPDISCOVER message from Client-4.	The DUT must not transmit a DHCPOFFER.

## prplOS.1.2.20: DHCPv4 Address Assigned based on Hardware Address

**Purpose:** Ensure DHCPv4 Server properly assigns addresses based on hardware address.

**Parameters:**

Device.DHCPv4.Server.Pool.<LAN>	
Enable	true
AllowDevices	All
MaxAddress	<Max Address in range on LAN>
MinAddress	<Min Address in range on LAN>

Device.DHCPv4.Server.Pool.<Y>	
Enable	true
Chaddr	<MAC address of Client-1>
ChaddrExclude	false
ChaddrMask	FF:FF:FF:FF:FF:FF
MinAddress	<Address within LAN subnet that does not overlap with the LAN Pool range>
MaxAddress	<Address within LAN subnet that does not overlap with the LAN Pool range>

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part. Client-1 and Client-3 have the same OUI.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.DHCPv4.Server.Pool.<Y> object with the parameters specified.	

2.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCPOFFER.
3.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 with an address in DHCP pool Y.
4.	Transmit a DHCPDISCOVER message from Client-2.	The DUT must transmit a DHCPOFFER.
5.	Transmit a DHCPREQUEST message from Client-2 to the DUT.	The DUT must transmit a DHCPACK to Client-2 with an address in the LAN address pool.
6.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>.ChaddrExclude=true.	
7.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCPOFFER.
8.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 with an address in the LAN address pool.
9.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>.ChaddrExclude=false.	
10.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>.ChaddrMask=FF:FF:FF:00:00:00.	
11.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCPOFFER.
12.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 with an address in DHCP pool Y.
13.	Transmit a DHCPDISCOVER message from Client-2.	The DUT must transmit a DHCPOFFER.
14.	Transmit a DHCPREQUEST message from Client-2 to the DUT.	The DUT must transmit a DHCPACK to Client-1 with an address in DHCP pool Y.

## prplOS.1.2.21: DHCPv4 Address assignment based on Client ID

**Purpose:** Ensure DHCPv4 Server properly assigns addresses based on client id.

**Parameters:**

Device.DHCPv4.Server.Pool.<LAN Instance>.	
Enable	true
AllowDevices	All
MaxAddress	<Max Address in range on LAN>
MinAddress	<Min Address in range on LAN>

Device.DHCPv4.Server.Pool.<Y>	
Enable	true
ClientID	<Client-1 ID>
ClientIDExclude	false
MaxAddress	<Address within LAN subnet that does not overlap with the LAN Pool range>
MinAddress	<Address within LAN subnet that does not overlap with the LAN Pool range>

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.DHCPv4.Server.Pool.<Y> object with the parameters specified.	
2.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCP OFFER.
3.	Transmit a DHCPREQUEST	The DUT must transmit a DHCPACK

	message from Client-1 to the DUT.	to Client-1 with an address in DHCP pool Y.
4.	Transmit a DHCPDISCOVER message from Client-2.	The DUT must transmit a DHCPOFFER.
5.	Transmit a DHCPREQUEST message from Client-2 to the DUT.	The DUT must transmit a DHCPACK to Client-2 with an address in the LAN address pool.
6.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>. ClientIDExclude=true.	
7.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCPOFFER.
8.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 with an address in the LAN address pool.
9.	Transmit a DHCPDISCOVER message from Client-2.	The DUT must transmit a DHCPOFFER.
10.	Transmit a DHCPREQUEST message from Client-2 to the DUT.	The DUT must transmit a DHCPACK to Client-2 with an address in the LAN address pool.

## prpIOS.1.2.22: DHCPv4 Address assignment based on UserClass ID

**Purpose:** Ensure DHCPv4 Server properly assigns addresses based on user class id.

**Parameters:**

Device.DHCPv4.Server.Pool.<LAN>	
Enable	true
AllowDevices	All
MaxAddress	<Max Address in range on LAN>
MinAddress	<Min Address in range on LAN>

Device.DHCPv4.Server.Pool.<Y>	
Enable	true
UserClassID	<UserClassID-1>
UserClassIDExclude	false
MaxAddress	<Address within LAN subnet that does not overlap with the LAN Pool range>
MinAddress	<Address within LAN subnet that does not overlap with the LAN Pool range>

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.DHCPv4.Server.Pool.<Y> object with the parameters specified.	
2.	Transmit a DHCPDISCOVER message from Client-1 with a UserClassID option with a value of	The DUT must transmit a DHCPOFFER.

	<UserClassID-1>.	
3.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 with an address in DHCP pool Y.
4.	Transmit a DHCPDISCOVER message from Client-2.	The DUT must transmit a DHCPOFFER.
5.	Transmit a DHCPREQUEST message from Client-2 to the DUT.	The DUT must transmit a DHCPACK to Client-2 with an address in the LAN address pool.
6.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>.UserClassIDExclude=true.	
7.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCPOFFER.
8.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 with an address in the LAN address pool
9.	Transmit a DHCPDISCOVER message from Client-2.	The DUT must transmit a DHCPOFFER.
10.	Transmit a DHCPREQUEST message from Client-2 to the DUT.	The DUT must transmit a DHCPACK to Client-2 with an address in the LAN address pool.

## prplOS.1.2.23: DHCPv4 Address assignment based on VendorClass ID

**Purpose:** Ensure DHCPv4 Server properly assigns addresses based on vendor class id.

**Parameters:**

Device.DHCPv4.Server.Pool.<LAN>	
Enable	true
AllowDevices	All
MaxAddress	<Max Address in range on LAN>
MinAddress	<Min Address in range on LAN>

Device.DHCPv4.Server.Pool.<Y>	
Enable	true
VendorClassID	<VendorClassID-1>
VendorClassIDExclude	false
MaxAddress	<Address within LAN subnet that does not overlap with the LAN Pool range>
MinAddress	<Address within LAN subnet that does not overlap with the LAN Pool range>

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.DHCPv4.Server.Pool.<Y> object with the parameters specified.	
2.	Transmit a DHCPDISCOVER message from Client-1 with a VendorClassID option with a value of	The DUT must transmit a DHCPOFFER.

	<VendorClassID-1>.	
3.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 with an address in DHCP pool Y.
4.	Transmit a DHCPDISCOVER message from Client-2.	The DUT must transmit a DHCPOFFER.
5.	Transmit a DHCPREQUEST message from Client-2 to the DUT.	The DUT must transmit a DHCPACK to Client-2 with an address in the LAN address pool.
6.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>.VendorIDExclude=true.	
7.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCPOFFER.
8.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 with an address in the LAN address pool.
9.	Transmit a DHCPDISCOVER message from Client-2.	The DUT must transmit a DHCPOFFER.
10.	Transmit a DHCPREQUEST message from Client-2 to the DUT.	The DUT must transmit a DHCPACK to Client-2 with an address in the LAN address pool.

## prpIOS.1.2.24: DHCPv4 Address assignment based on Reserved

**Purpose:** Ensure DHCPv4 Server properly assigns addresses based on reserved address.

**Parameters:**

Device.DHCPv4.Server.Pool.<LAN>.	
Enable	true
AllowDevices	All
MaxAddress	<Max Address in range on LAN>
MinAddress	<Address before MaxAddress>
ReservedAddresses	<MaxAddress>

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the above parameters so that the LAN Address pool contains two addresses and the ReservedAddresses parameter contains the MaxAddress address.	
2.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCPOFFER.
3.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 with an address with the MinAddress.
4.	Transmit a DHCPDISCOVER message from Client-2.	The DUT NOT must transmit a DHCPOFFER.

## prplOS.1.2.25: DHCPv4 Address assigns static address

**Purpose:** Ensure DHCPv4 Server properly assigns a static address based on the mac address of the client.

**Parameters:**

Device.DHCPv4.Server.Pool.<LAN>.	
Enable	true
AllowDevices	All

Device.DHCPv4.Server.Pool.<LAN>.StaticAddress.<Y>.	
Enable	true
Chaddr	<MAC address of Client-1>
Yiaddr	<Address Y in LAN Pool>

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.DHCPv4.Server.Pool.<LAN Instance>.Static.<Y> object with the parameters specified.	
2.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCPOFFER.
3.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 with Address Y
4.	Transmit a DHCPDISCOVER message from Client-2.	The DUT must transmit a DHCPOFFER.
5.	Transmit a DHCPREQUEST message from Client-2 to the DUT.	The DUT must transmit a DHCPACK to Client-2 with an address in the

		DHCP range, that is not Address Y.
6.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>.Static.<Y>.Chaddr=<MAC address of Client-2>.	
7.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCPOFFER.
8.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 with an address in the DHCP range, that is not Address Y.
9.	Transmit a DHCPDISCOVER message from Client-2.	The DUT must transmit a DHCPOFFER.
10.	Transmit a DHCPREQUEST message from Client-2 to the DUT.	The DUT must transmit a DHCPACK to Client-2 with Address Y.
11.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>.Static.<Y>.Enable=false.	
12.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCPOFFER.
13.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 with an address in the DHCP range, that is not Address Y.
14.	Transmit a DHCPDISCOVER message from Client-2.	The DUT must transmit a DHCPOFFER.
15.	Transmit a DHCPREQUEST message from Client-2 to the DUT.	The DUT must transmit a DHCPACK to Client-2 with Address Y.

## prplOS.1.2.26: DHCPv4 Server DNS Servers

**Purpose:** Ensure DHCPv4 Server properly advertises DNS Servers.

**Parameters:**

Device.DHCPv4.Server.Pool.<LAN>.	
Enable	true

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>.DNSServers=<IP address DNS-Server-1>.	
2.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCP OFFER to Client-1.
3.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 containing the DNS Option with the IP address of DNS-Server-1.
4.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>.DNSServers=<IP address DNS-Server-1>,<IP address DNS-Server-2>.	
5.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCP OFFER to Client-1.
6.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 containing the DNS Option with the IP addresses of DNS-Server-1 and DNS-Server-2.
7.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>.	

	DNSServers=<IP address DNS-Server-1>,<IP address DNS-Server-2>, <IP address of DNS-Server-3>.	
8.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCPOFFER to Client-1.
9.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 containing the DNS Option with the IP addresses of DNS-Server-1, DNS-Server-2 and DNS-Server-3.
10.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>. DNSServers=<IP address DNS-Server-1>.	
11.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCPOFFER to Client-1.
12.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 containing the DNS Option with the IP address of DNS-Server-1.

## prplOS.1.2.27: DHCPv4 Server Domain Name

**Purpose:** Ensure DHCPv4 Server properly advertises domain name.

**Parameters:**

Device.DHCPv4.Server.Pool.<LAN>.	
Enable	true

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>. DomainName=test.example.com	
2.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCP OFFER to Client-1.
3.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 containing the Domain Name Option with the test.example.com.

## prpIOS.1.2.28: DHCPv4 Server Subnet Mask

**Purpose:** Ensure DHCPv4 Server properly advertises subnet mask.

**Parameters:**

Device.DHCPv4.Server.Pool.<LAN>.	
Enable	true
MaxAddress	<Max Address in range on LAN>
MinAddress	<Min Address in range on LAN>
SubnetMask	255.255.255.0

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>. SubnetMask=255.0.0.0	
2.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCP OFFER to Client-1.
3.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 containing a subnet mask option with a value of 255.0.0.0.

## prplOS.1.2.29: DHCPv4 Server IPRouters

**Purpose:** Ensure DHCPv4 Server properly advertises default routers on the LAN.

**Parameters:**

Device.DHCPv4.Server.Pool.<LAN>.	
Enable	true

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv4.Server.Pool.<LAN Instance>.IPRouters=<DUT LAN address>.	
2.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCPOFFER to Client-1.
3.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 containing an IPRouters option with the LAN address of the DUT.
4.	Set the parameter Device.DHCPv4.Server.Pool.<LAN Instance>.IPRouters=<Address not assigned on the LAN>	
5.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCPOFFER to Client-1.
6.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 containing an IPRouters option with address from Step 4.

## prplOS.1.2.30: DHCPv4 Server Option

**Purpose:** Ensure DHCPv4 Server properly advertises DHCP Options.

**Parameters:**

Device.DHCPv4.Server.Pool.<LAN>.	
Enable	true

Device.DHCPv4.Server.<LAN>.Option.<i>.	
Enable	true
Tag	46
Value	0104

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add the object Device.DHCPv4.Server.Pool.<LAN>.Option.<i> as specified.	
2.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCP OFFER to Client-1.
3.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 containing an NetBIOS over TCP/IP Node Type option with a M-node (4) type.
4.	Set the parameter Device.DHCPv4.Server.Pool.<LAN>.Option.<i>.Enabled=false.	
5.	Transmit a DHCPDISCOVER message from Client-1.	The DUT must transmit a DHCP OFFER to Client-1.
6.	Transmit a DHCPREQUEST message from Client-1 to the DUT.	The DUT must transmit a DHCPACK to Client-1 that doesn't contain the

		NetBIOS over TCP/IP Node Type option.
--	--	---------------------------------------

## Group 3: DHCPv6

### Scope

The following test covers DHCPv6 support of a prplOS implementation.

### Overview

The tests in this group verify the DUT properly implements DHCPv6 configuration for both WAN and LAN interfaces.

### prplOS.1.3.1: DHCPv6 Client Status

**Purpose:** Ensure the status of the DHCPv6 Client can be verified.

**Parameters:**

Device.DHCPv6.Client	
Enable	true
Interface	<WAN>
DUID	<returned from device>
RapidCommit	true
RequestAddresses	true
RequestPrefixes	true

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv6.Client.<WAN>.Enable=false.	
2.	Allow time for the DUT to process the set.	
3.	Get the parameter Device.DHCPv6.Client.<WAN>.Status	The value returned from the DUT must be "Disabled".
4.	Set the parameter Device.DHCPv6.Client.<WAN>.Enable=true.	
5.	Get the parameter Device.DHCPv6.Client.<WAN>.Status	The value returned from the DUT must be "Enabled".

## prplOS.1.3.2: DHCPv6 Client IA\_NA

**Purpose:** Ensure DHCPv6 IA\_NA can be enabled and disabled on the DHCPv6 Client.

**Parameters:**

Device.DHCPv6.Client	
Enable	true
Interface	WAN Interface
DUID	<returned from device>
RapidCommit	true
RequestAddresses	true
RequestPrefixes	true

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv6.Client.<WAN>.RequestAddresses=false.	
2.	Wait for IA_NA lifetime.	DUT must not transmit any DHCPv6 Solicit, Renew or Rebind messages containing IA_NA options.
3.	Set the parameter Device.DHCPv6.Client.<WAN>.RequestAddresses=true.	
4.	Allow time for the DUT to process the set.	The DUT must transmit a DHCPv6 Solicit message.
5.	DHCP Server responds with a IA_NA containing a valid IPv6 address with a lifetime of 80 seconds.	
6.	Wait T1 seconds.	

7.		The DUT must transmit a DHCPv6 Renew message with an assigned address in the IA_NA.
----	--	---

## prplOS.1.3.3: DHCPv6 Client IA\_PD

**Purpose:** Ensure DHCPv6 IA\_PD can be enabled and disabled on the DHCPv6 Client.

**Parameters:**

Device.DHCPv6.Client	
Enable	true
Interface	<WAN>
DUID	<returned from device>
RapidCommit	true
RequestAddresses	true
RequestPrefixes	true

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv6.Client.<WAN>.RequestPrefixes=false.	
2.	Wait for IA_PD lifetime.	DUT must not transmit any DHCPv6 Solicit, Renew or Rebind messages containing IA_PD options.
3.	Set the parameter Device.DHCPv6.Client.<WAN>.RequestPrefixes=true.	
4.	Allow time for the DUT to process the set.	The DUT must transmit a DHCPv6 Solicit message.
5.	DHCP Server responds with a IA_PD containing a valid IPv6 prefix.	
6.	Wait T1 seconds.	

7.		The DUT must transmit a DHCPv6 Renew message with an assigned prefix in the IA_PD.
----	--	--

### prplOS.1.3.4: DHCPv6 Client Rapid Commit

**Purpose:** Ensure Rapid Commit option can be enabled and disabled on the DHCPv6 Client.

**Parameters:**

Device.DHCPv6.Client	
Enable	true
Interface	<WAN>
DUID	<returned from device>
RapidCommit	true
RequestAddresses	true
RequestPrefixes	true

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv6.Client.<WAN>.Rapid Commit=false.	
2.	Wait for IA_NA lifetime.	
3.		DUT transmits a DHCPv6 Solicit message. The message must not contain a Rapid Commit option.
4.	Set the parameter Device.DHCPv6.Client.<WAN>.Rapid Commit=true.	
5.	Wait for IA_NA lifetime.	
6.		DUT must transmit a DHCPv6 Solicit message. The message must contain a Rapid Commit option.

7.	The DHCP Server transmits a DHCP Reply message with a valid IA_NA and IA_PD.	
8.	Wait for IA_NA lifetime.	The DUT must not transmit any DHCPv6 message indicating it processed the Rapid Commit.
9.		The DUT must transmit DHCPv6 Renew message with the IA_NA and IA_PD Options from Step 7.

## prplOS.1.3.5: DHCPv6 Client Renew (T1 Timer)

**Purpose:** Verify that the T1 timer on the DHCPv6 Client.

**Parameters:**

Device.DHCPv6.Client	
Enable	true
Interface	<WAN>
DUID	<returned from device>
RapidCommit	true
RequestAddresses	true
RequestPrefixes	true

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

The DHCPv6 assigned address lifetime before the test starts should be 80 seconds.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv6.Client.<WAN>.SuggestedT1=20	
2.	Allow for the current leases to expire by not responding to any Renew or Rebind messages.	The DUT transmits a DHCPv6 Solicit message after current leases expire.
3.		The DUT transmits a DHCPv6 Solicit messages.
4.	The DHCPv6 Server assigns the DUT an address (IA_NA) with a T1 value set to 0.	
5.	Wait for 20 seconds.	
6.	Wait for 5 seconds for DHCPv6	The DUT transmits a DHCPv6

	messages.	Renew message.
7.	Set the parameter Device.DHCPv6.Client.<WAN>.SuggestedT1=40.	
8.	Allow for the current leases to expire by not responding to any Renew messages.	The DUT transmits a DHCPv6 Solicit message after current leases expire.
9.		The DUT transmits a DHCPv6 Solicit messages.
10.	The DHCPv6 Server assigns the DUT an address (IA_NA) with a T1 value set to 0.	
11.	Wait for 40 seconds.	
12.	Wait for 5 seconds for a DHCPv6 messages.	The DUT transmits a DHCPv6 Renew message.

## prplOS.1.3.6: DHCPv6 Client Rebind (T2 Timer)

**Purpose:** Verify that the T2 timer on the DHCPv6 Client.

**Parameters:**

Device.DHCPv6.Client	
Enable	true
Interface	<WAN>
DUID	<returned from device>
RapidCommit	true
RequestAddresses	true
RequestPrefixes	true

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

The DHCPv6 assigned address lifetime before the test starts should be 80 seconds.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv6.Client.<WAN>.SuggestedT2=40	
2.	Allow for the current leases to expire by not responding to any Renew or Rebind messages.	The DUT transmits a DHCPv6 Solicit message after current leases expire.
3.		The DUT transmits a DHCPv6 Solicit messages.
4.	The DHCPv6 Server assigns the DUT an address (IA_NA) with a T2 value of 0.	
5.	Wait for 40 seconds.	
6.	Wait for 10 seconds for DHCPv6	The DUT transmits a DHCPv6

	messages.	Rebind message.
7.	Set the parameter Device.DHCPv6.Client.<WAN>.SuggestedT2=80.	
8.	Allow for the current leases to expire by not responding to any Renew or Rebind messages.	The DUT transmits a DHCPv6 Solicit message after current leases expire.
9.		The DUT transmits a DHCPv6 Solicit messages with a T2 timer of 80 seconds.
10.	The DHCPv6 Server assigns the DUT an address (IA_NA) with a T2 value of 0.	
11.	Wait for 80 seconds.	
12.	Wait for 10 seconds for a DHCPv6 messages.	The DUT transmits a DHCPv6 Rebind message.

## prplOS.1.3.7: DHCPv6 Client Requested Options

**Purpose:** Verify that the DHCP client transmits DHCPv6 options as requested.

**Parameters:**

Device.DHCPv6.Client	
Enable	true
Interface	<WAN>
DUID	<returned from device>
RapidCommit	true
RequestAddresses	true
RequestPrefixes	true
RequestedOptions	23,31,32

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv6.Client.<WAN>.RequestedOptions="23,24,31,32"	
2.	Disable DHCP Server and wait for IA_NA lifetime.	
3.	Enable the DHCP Server and wait for DHCPv6 messages from the DUT.	The DUT transmits a DHCPv6 Solicit message with Domain Search List Option (24).
4.	Wait for T1 seconds.	The DUT transmits a DHCPv6 Renew message containing the Domain Search List Option.
5.	Set the parameter Device.DHCPv6.Client.<WAN	

	Instance>.RequestedOptions="23,31,32"	
6.	Disable DHCP Server and wait for IA_NA seconds.	
7.	Enable the DHCP Server and wait for DHCPv6 messages from the DUT.	The DUT transmits a DHCPv6 Solicit message without Domain Search List Option (24).

## prplOS.1.3.8: DHCPv6 Client Server Information

**Purpose:** Verify the DHCP Server information is correct from the DHCP Client.

**Parameters:**

Device.DHCPv6.Client	
Enable	true
Interface	WAN Interface
DUID	<returned from device>
RapidCommit	true
RequestAddresses	true
RequestPrefixes	true
RequestedOptions	23,31,32

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.DHCPv6.Client.<WAN>.Server.<DHCP Server>.SourceAddress	The IPv6 source address of the DHCP Server must be returned.
2.	Get parameter Device.DHCPv6.Client.<WAN>.Server.<DHCP Server>.DUID	The DUID of the DHCP Server must be returned.

### prplOS.1.3.9: DHCPv6 Client Sent Options

**Purpose:** Verify that the DHCP client properly reports the sent DHCP options.

**Parameters:**

Device.DHCPv6.Client.<Y>.SentOptions	
Enable	true
Tag	15
Value	00021234

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.DHCPv6.Client.<Y> object with the parameters specified in the table above.	
2.		The DUT must transmit a DHCPv6 Solicit message with the User Class Option.
3.	The DHCPv6-Server transmits a DHCPv6 Advertise message containing a User Class Option in response.	The DUT must transmit a DHCPv6 Request message with the User Class Option containing a value in the parameter table.

### prplOS.1.3.10: DHCPv6 Client Received Options

**Purpose:** Verify that the DHCP client properly reports the received DHCP options.

**Parameters:**

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Allow for the current leases to expire by not responding to any Renew or Rebind messages.	The DUT transmits a DHCPv6 Solicit message after current leases expire.
2.		The DUT transmits a DHCPv6 Solicit messages.
3.	The DHCPv6 Server assigns the DUT an address (IA_NA) and includes a Vendor Specific Information Option.	
4.	Get the object Device.DHCPv6.Client.<WAN Instance>.ReceivedOption	The DUT must return a row in the Object for Vendor Specific Information Option with values received from the DHCP Server.

### prplOS.1.3.11: Enable DHCPv6 Server

**Purpose:** Ensure DHCPv6 Server can be enabled and disabled.

**Parameters:**

Device.DHCPv6.Server	
Enable	true

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv6.Server.Enable=false.	
2.	Allow time for the DUT to process the set.	
3.	Transmit a DHCPv6 Solicit message from Client-1.	Ensure the DUT does not transmit any DHCPv6 message on the LAN interface.
4.	Transmit a DHCPv6 Information Request message from Client-1.	Ensure the DUT does not transmit any DHCPv6 message on the LAN interface.
5.	Set the parameter Device.DHCPv6.Server.Enable=true.	
6.	Allow time for the DUT to process the set.	
7.	Transmit a DHCPv6 Solicit message from Client-1.	The DUT must transmit a DHCPv6 Advertise in response.
8.	Transmit a DHCPv6 Request message from Client-1 to the DUT.	The DUT must transmit a DHCPv6 Reply in response.
9.	Transmit a DHCPv6 Information Request message from Client-1.	The DUT must transmit a DHCPv6 Information Reply in response.

## prplOS.1.3.12: DHCPv6 Server Pool Enable

**Purpose:** Verify the DHCPv6 Server pool can be enabled and disabled.

**Parameters:**

Device.DHCPv6.Server.Pool.<LAN Instance>.	
Enable	true

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.Enable=false.	
2.	Allow time for the DUT to process the set.	
3.	Transmit a DHCPv6 Solicit message from Client-1.	Ensure the DUT does not transmit any DHCPv6 message on the LAN interface.
4.	Transmit a DHCPv6 Information Request message from Client-1.	Ensure the DUT does not transmit any DHCPv6 message on the LAN interface.
5.	Set the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.Enable=true.	
6.	Allow time for the DUT to process the set.	
7.	Transmit a DHCPv6 Solicit message from Client-1.	The DUT must transmit a DHCPv6 Advertise in response.
8.	Transmit a DHCPv6 Request message from Client-1 to the DUT.	The DUT must transmit a DHCPv6 Reply in response.
9.	Transmit a DHCPv6 Information Request message from Client-1.	The DUT must transmit a DHCPv6 Information Reply in response.

## prplOS.1.3.13: DHCPv6 Server Pool Status

**Purpose:** Verify the DHCPv6 Server pool status.

**Parameters:**

Device.DHCPv6.Server.Pool.<LAN Instance>.	
Enable	true

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.Enable=false.	
2.	Wait for 10 seconds.	
3.	Get the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.Status	The value returned from the DUT must be "Disabled".
4.	Set the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.Enable=true.	
5.	Wait for 10 seconds	
6.	Get the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.Status	The value returned from the DUT must be "Enabled".

## prplOS.1.3.14: Enable DHCPv6 Server IA\_NA

**Purpose:** Ensure DHCPv6 Server can enable and disable IA\_NA offering on the LAN interface.

**Parameters:**

Device.DHCPv6.Server.Pool.<LAN Instance>	
Enable	true
IANAEnable	true
IAPDEnable	true

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.IANAEnable=false.	
2.	Allow time for the DUT to process the set.	
3.	Transmit a DHCPv6 Solicit message from Client-1 requesting an IA_NA option.	Ensure the DUT must not offer an IA_NA option to Client-1 in the DHCPv6 Advertise message.
4.	Transmit a DHCPv6 Information Request message from Client-1.	The DUT must transmit a DHCPv6 Reply in response.
5.	Set the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.IANAEnable=true.	
6.	Allow time for the DUT to process the set.	
7.	Transmit a DHCPv6 Solicit message from Client-1 requesting an IA_NA option.	The DUT must transmit a DHCPv6 Advertise message with an IA_NA option in response.
8.	Transmit a DHCPv6 Information	The DUT must transmit a DHCPv6

	Request message from Client-1.	Information Reply in response.
--	--------------------------------	--------------------------------

## prplOS.1.3.15: Enable DHCPv6 Server IA\_PD

**Purpose:** Ensure DHCPv6 Server can enable and disable IA\_PD offering on the LAN interface.

**Parameters:**

Device.DHCPv6.Server.Pool.<LAN Instance>	
IANAEnable	true
IAPDEnable	true

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.IAPDEnable=false.	
2.	Allow time for the DUT to process the set.	
3.	Transmit a DHCPv6 Solicit message from Client-1 requesting an IA_PD option.	Ensure the DUT must not offer an IA_PD option to Client-1 in the DHCPv6 Advertise message.
4.	Transmit a DHCPv6 Information Request message from Client-1.	The DUT must transmit a DHCPv6 Reply in response.
5.	Set the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.IAPDEnable=true.	
6.	Allow time for the DUT to process the set.	
7.	Transmit a DHCPv6 Solicit message from Client-1 requesting an IA_PD option.	The DUT must transmit a DHCPv6 Advertise message with an IA_PD option in response.
8.	Transmit a DHCPv6 Information Request message from Client-1.	The DUT must transmit a DHCPv6 Information Reply in response.

## prplOS.1.3.16: DHCPv6 Server Report Clients Active.

**Purpose:** Ensure DHCPv6 Server reports if a DHCPv6 Client is present on the LAN.

**Parameters:**

Device.DHCPv6.Server.Pool.<LAN Instance>	
Enable	true
IANAEnable	true
IAPDEnable	true

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Transmit a DHCPv6 Solicit message from Client-1.	The DUT must transmit a DHCPv6 Advertise to Client-1 with an IA_NA option.
2.	Transmit a DHCPv6 Request message from Client-1 to the DUT.	The DUT must transmit a DHCPv6 Reply to Client-1 with an IA_NA option containing a valid IPv6 address.
3.	Get the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.Client.<Client-1 Instance>.SourceAddress	The DUT must return the IPv6 source address of Client-1.
4.	Get the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.Client.<Client-1 Instance>.Active	The DUT must return a value of true.

## prpIOS.1.3.17: DHCPv6 Server Report Clients Assigned Address

**Purpose:** Ensure DHCPv6 Server reports if a DHCPv6 Client assigned address.

**Parameters:**

Device.DHCPv6.Server.Pool.<LAN Instance>	
Enable	true
IANAEnable	true
IAPDEnable	true

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Transmit a DHCPv6 Solicit message from Client-1 containing IA_NA option.	The DUT must transmit a DHCPv6 Advertise to Client-1 with an IA_NA option.
2.	Transmit a DHCPv6 Request message with an IA_NA from Client-1 to the DUT.	The DUT must transmit a DHCPv6 Reply to Client-1 with an IA_NA option containing a valid IPv6 address with a preferred and valid lifetime greater than 0.
3.	Allow time for the DUT to process the DHCP message.	
4.	Get the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.Client.<Client-1>.IPv6Address.1.IPAddress	The DUT must return the address of Client-1 assigned in Step 2.
5.	Get the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.Client.<Client-1>.IPv6Address.1.PreferredLifetime	The DUT must return a preferred lifetime that is less than the lifetime assigned in Step 2.
6.	Get the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.Client.<Client-	The DUT must return a valid lifetime that is less than the lifetime assigned in Step 2.

	1>.IPv6Address.1.ValidLifetime	
--	--------------------------------	--

## prpIOS.1.3.18: DHCPv6 Server Report Clients Assigned Prefixes

**Purpose:** Ensure DHCPv6 Server reports if a DHCPv6 Client assigned prefixes.

**Parameters:**

Device.DHCPv6.Server.Pool.<LAN Instance>	
Enable	true
IANAEnable	true
IAPDEnable	true

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Transmit a DHCPv6 Solicit message containing an IA_PD from Client-1.	The DUT must transmit a DHCPv6 Advertise to Client-1 with an IA_PD option.
2.	Transmit a DHCPv6 Request message containing an IA_PD from Client-1 to the DUT.	The DUT must transmit a DHCPv6 Reply to Client-1 with an IA_PD option containing a valid IPv6 prefix with a preferred and valid lifetime greater than 0.
3.	Allow time for the DUT to process the DHCP message.	
4.	Get the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.Client.<Client-1>.IPv6Prefix.1.Prefix	The DUT must return the prefix of Client-1 assigned in Step 2.
5.	Get the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.Client.<Client-1>.IPv6Prefix.1.PreferredLifetime	The DUT must return a preferred lifetime that is less than the lifetime assigned in Step 2.
6.	Get the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.Client.<Client-	The DUT must return a valid lifetime that is less than the lifetime assigned in Step 2.

	1>.IPv6Prefix.1.ValidLifetime	
--	-------------------------------	--

## prplOS.1.3.19: DHCPv6 Server Options

**Purpose:** Ensure DHCPv6 Server reports DHCP options sent to the clients.

**Parameters:**

Device.DHCPv6.Server.Pool.<LAN Instance>	
Enable	true
IANAEnable	true
IAPDEnable	true

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.Options.1.Tag=17	
2.	Set the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.Options.1.Value to an appropriate value.	
3.	Set the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.Options.1.Enable=true	
4.	Allow time for the DUT to process the set.	
5.	Transmit a DHCPv6 Solicit message from Client-1.	The DUT must transmit a DHCPv6 Advertise to Client-1 with Vendor Specific Information (17) option.
6.	Set the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.Options.1.Enable=false	
7.	Allow time for the DUT to process the set.	

8.	Transmit a DHCPv6 Solicit message from Client-1 containing ORO Option with a SOL_MAX_RT and an IA_NA Option.	The DUT must transmit a DHCPv6 Advertise to Client-1 without the Vendor Specific Class (16) Option.
----	--	---

## prplOS.1.3.20: Manually Assign Address in DHCPv6 Pool

**Purpose:** Ensure DHCPv6 Server will assign manually configured addresses on the LAN interface.

**Parameters:**

Device.DHCPv6.Server.Pool.<LAN Instance>	
Enable	true
IANAEnable	true
IAPDEnable	true

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part. The LAN interface has a static ULA address configured.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.IANAManualPrefixes=Device.IP.Interface.<LAN ULA Instance>.IPv6Prefix	
2.	Allow time for the DUT to process the set.	
3.	Transmit a DHCPv6 Solicit message from Client-1 requesting an IA_NA option.	Ensure the DUT must offer an IA_NA to Client-1 in the DHCPv6 Advertise message with IAAddress in the manually assigned address prefix.
4.	Transmit a DHCPv6 Request message from Client-1 requesting an IA_NA option.	Ensure the DUT must offer an IA_NA to Client-1 in the DHCPv6 Reply message with IAAddress in the manually assigned address prefix.

### prplOS.1.3.21: DHCPv6 Server IA\_NA Address Available

**Purpose:** Ensure DHCPv6 Server reports the addresses pool being assigned on the LAN interface.

**Parameters:**

Device.DHCPv6.Server.Pool.<LAN Instance>	
Enable	true
IANAEnable	true
IAPDEnable	true

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part. The LAN interface has a static ULA address configured.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.IANAManualPrefixes=Device.IP.Interface.<LAN ULA Instance>.IPv6Prefix	
2.	Allow time for the DUT to process the set.	
3.	Get the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.IANAPrefixes	The DUT must return Device.IP.Interface.<LAN ULA Instance>.IPv6Prefix has one the path names returned.

## prplOS.1.3.22: Manually Assign Prefixes in DHCPv6 Pool

**Purpose:** Ensure DHCPv6 Server will assign manually configured prefixes on the LAN interface.

**Parameters:**

Device.DHCPv6.Server.Pool.<LAN Instance>	
Enable	true
IANAEnable	true
IAPDEnable	true

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part. The LAN interface has a static ULA prefix configured.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.IAPDManualPrefixes=Device.IP.Interface.<LAN ULA Prefix Instance>.IPv6Prefix	
2.	Allow time for the DUT to process the set.	
3.	Transmit a DHCPv6 Solicit message from Client-1 requesting an IA_PD option.	Ensure the DUT must offer an IA_PD to Client-1 in the DHCPv6 Advertise message with IAPrefix in the manually assigned address prefix.
4.	Transmit a DHCPv6 Request message from Client-1 requesting an IA_PD option.	Ensure the DUT must offer an IA_PD to Client-1 in the DHCPv6 Reply message with IAPrefix in the manually assigned address prefix.

### prplOS.1.3.23: DHCPv6 Server IA\_PD Address Available

**Purpose:** Ensure DHCPv6 Server reports the prefix pool being assigned on the LAN interface.

**Parameters:**

Device.DHCPv6.Server.Pool.<LAN Instance>	
Enable	true
IANAEnable	true
IAPDEnable	true

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part. The LAN interface has a static ULA prefix configured.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.IAPDManualPrefixes=Device.IP.Interface.<LAN ULA Instance>.IPv6Prefix	
2.	Allow time for the DUT to process the set.	
3.	Get the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.IAPDPrefixes	The DUT must return Device.IP.Interface.<LAN ULA Instance>.IPv6Prefix has one the path names returned.

### prplOS.1.3.24: DHCPv6 Assign information by DUID

**Purpose:** Ensure DHCPv6 Server assigns addresses based on DUID.

**Parameters:**

Device.IP.Interface.<A>.Prefix	
Enable	true
Prefix	2001:0001:0000:0001::
StaticType	Static

Device.DHCPv6.Server.Pool.<LAN Instance>	
Enable	true
IANAEnable	true
IAPDEnable	true

Device.DHCPv6.Server.Pool.<Y>	
Enable	true
IANAEnable	true
IAPDEnable	true
DUID	<Client-1 DUID>
DUIDExclude	false
IANAManualPrefixes	Device.IP.Interface.<A>.Prefix

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.DHCPv6.Server.Pool.<Y> object with the parameters specified in the table above.	
2.	Get the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.IANAPrefixes	The value returned from the DUT must be the Path Name of a row in the IP.Interface.{i}.IPv6Prefix. table.
3.	Get the parameter Prefix using the Path Name returned in Step 2.	The DUT must return a valid IPv6 Prefix.
4.	Allow time for the DUT to process the set.	
5.	Transmit a DHCPv6 Solicit message from Client-1.	The DUT must transmit a DHCPv6 Advertise with the address in 2001:0001:0000:0001::/64 range in response.
6.	Transmit a DHCPv6 Request message from Client-1 to the DUT.	The DUT must transmit a DHCPv6 Reply with the address in 2001:0001:0000:0001::/64 range in response.
7.	Transmit a DHCPv6 Solicit message from Client-2.	The DUT must transmit a DHCPv6 Advertise in response using an address from Step 3.
8.	Transmit a DHCPv6 Request message from Client-2.	The DUT must transmit a DHCPv6 Reply in response using an address range from address in Step 3.
9.	Set the parameter Device.DHCPv6.Server.Pool.<Y>.DUIDExclude=true.	
10.	Allow time for the DUT to process the set.	
11.	Transmit a DHCPv6 Solicit message from Client-1.	The DUT must transmit a DHCPv6 Advertise in response using an address from Step 3.
12.	Transmit a DHCPv6 Request message from Client-1 to the DUT.	The DUT must transmit a DHCPv6 Advertise in response using an address from Step 3.

13.	Transmit a DHCPv6 Solicit message from Client-2.	The DUT must transmit a DHCPv6 Advertise in response using an address from Step 3.
14.	Transmit a DHCPv6 Request message from Client-2.	The DUT must transmit a DHCPv6 Reply in response using an address range from address in Step 3.

### prplOS.1.3.25: DHCPv6 Assign information by Source Address

**Purpose:** Ensure DHCPv6 Server assigns addresses based on Source Address.

**Parameters:**

Device.IP.Interface.<A>.Prefix	
Enable	true
Prefix	2001:0001:0000:0001::
StaticType	Static

Device.DHCPv6.Server.Pool.<LAN Instance>	
Enable	true
IANAEnable	true
IAPDEnable	true

Device.DHCPv6.Server.Pool.<Y>	
Enable	true
IANAEnable	true
IAPDEnable	true
SourceAddress	<Client-1 Link Local Address>
SourceAddressExclude	false
IANAManualPrefixes	Device.IP.Interface.<A>.Prefix

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part. The DHCPv6 assigned address lifetime before the test starts should be 80 seconds.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.DHCPv6.Server.Pool.<Y> object with the parameters specified.	
2.	Get the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.IANAPrefixes	The value returned from the DUT must be the Path Name of a row in the IP.Interface.{i}.IPv6Prefix. table.
3.	Get the parameter Prefix using the Path Name returned in Step 2.	The DUT must return a valid IPv6 Prefix.
4.	Allow time for the DUT to process the set.	
5.	Transmit a DHCPv6 Solicit message from Client-1.	The DUT must transmit a DHCPv6 Advertise with the address in 2001:0001:0000:0001::/64 range in response.
6.	Transmit a DHCPv6 Request message from Client-1 to the DUT.	The DUT must transmit a DHCPv6 Reply with the address in 2001:0001:0000:0001::/64 range in response.
7.	Transmit a DHCPv6 Solicit message from Client-2.	The DUT must transmit a DHCPv6 Advertise in response using an address from Step 3.
8.	Transmit a DHCPv6 Request message from Client-2.	The DUT must transmit a DHCPv6 Reply in response using an address range from address in Step 3.
9.	Set the parameter Device.DHCPv6.Server.Pool.<Y>.SourceAddressExclude=true.	
10.	Allow time for the DUT to process the set.	
11.	Transmit a DHCPv6 Solicit message from Client-1.	The DUT must transmit a DHCPv6 Advertise in response using an address from Step 3.
12.	Transmit a DHCPv6 Request message from Client-1 to the DUT.	The DUT must transmit a DHCPv6 Reply in response using an address from Step 3.

13.	Transmit a DHCPv6 Solicit message from Client-2.	The DUT must transmit a DHCPv6 Advertise in response using an address from Step 3.
14.	Transmit a DHCPv6 Request message from Client-2.	The DUT must transmit a DHCPv6 Reply in response using an address range from address in Step 3.

## prplOS.1.3.26: DHCPv6 Assign information by UserClassID

**Purpose:** Ensure DHCPv6 Server assigns addresses based on UserClassID.

**Parameters:**

Device.IP.Interface.<A>.Prefix	
Enable	true
Prefix	2001:0001:0000:0001::
StaticType	Static

Device.DHCPv6.Server.Pool.<LAN Instance>	
Enable	true
IANAEnable	true
IAPDEnable	true

Device.DHCPv6.Server.Pool.<Y>	
Enable	true
IANAEnable	true
IAPDEnable	true
UserClassID	<UserClassID-11>
UserClassExclude	false
IANAManualPrefixes	Device.IP.Interface.<A>.Prefix

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.DHCPv6.Server.Pool.<Y> object with the parameters specified.	
2.	Get the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.IANAPrefixes	The value returned from the DUT must be the Path Name of a row in the IP.Interface.{i}.IPv6Prefix. table.
3.	Get the parameter Prefix using the Path Name returned in Step 2.	The DUT must return a valid IPv6 Prefix.
4.	Allow time for the DUT to process the set.	
5.	Transmit a DHCPv6 Solicit message from Client-1 with a UserClassID Option in the ORO.	The DUT must transmit a DHCPv6 Advertise with the address in 2001:0001:0000:0001::/64 range in response.
6.	Transmit a DHCPv6 Request message from Client-1 to the DUT with a UserClassID Option with <UserClassID-1>.	The DUT must transmit a DHCPv6 Reply with the address in 2001:0001:0000:0001::/64 range in response.
7.	Transmit a DHCPv6 Solicit message from Client-2.	The DUT must transmit a DHCPv6 Advertise in response using an address from Step 3.
8.	Transmit a DHCPv6 Request message from Client-2.	The DUT must transmit a DHCPv6 Reply in response using an address range from address in Step 3.
9.	Set the parameter Device.DHCPv6.Server.Pool.<Y>.UserClassIDExclude=true.	
10.	Allow time for the DUT to process the set.	
11.	Transmit a DHCPv6 Solicit message from Client-1 with a UserClassID Option in the ORO.	The DUT must transmit a DHCPv6 Advertise in response using an address from Step 3.
12.	Transmit a DHCPv6 Request message from Client-1 to the DUT with a UserClassID Option with <UserClassID-1>.	The DUT must transmit a DHCPv6 Reply in response using an address from Step 3.

13.	Transmit a DHCPv6 Solicit message from Client-2.	The DUT must transmit a DHCPv6 Advertise in response using an address from Step 3.
14.	Transmit a DHCPv6 Request message from Client-2.	The DUT must transmit a DHCPv6 Reply in response using an address range from address in Step 3.

### prplOS.1.3.27: DHCPv6 Assign information by VendorClassID

**Purpose:** Ensure DHCPv6 Server assigns addresses based on VendorClassID.

**Parameters:**

Device.IP.Interface.<A>.Prefix	
Enable	true
Prefix	2001:0001:0000:0001::
StaticType	Static

Device.DHCPv6.Server.Pool.<LAN Instance>	
Enable	true
IANAEnable	true
IAPDEnable	true

Device.DHCPv6.Server.Pool.<Y>	
Enable	true
IANAEnable	true
IAPDEnable	true
UserClassID	<VendorClassID-1>
UserClassExclude	false
IANAManualPrefixes	Device.IP.Interface.<A>.Prefix

**Functionality Tags:** DHCPv6 Feature

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.DHCPv6.Server.Pool.<Y> object with the parameters specified in the table above.	
2.	Get the parameter Device.DHCPv6.Server.Pool.<LAN Instance>.IANAPrefixes	The value returned from the DUT must be the Path Name of a row in the IP.Interface.{i}.IPv6Prefix. table.
3.	Get the parameter Prefix using the Path Name returned in Step 2.	The DUT must return a valid IPv6 Prefix.
4.	Allow time for the DUT to process the set.	
5.	Transmit a DHCPv6 Solicit message from Client-1 with a VendorClassID Option in the ORO.	The DUT must transmit a DHCPv6 Advertise with the address in 2001:0001:0000:0001::/64 range in response.
6.	Transmit a DHCPv6 Request message from Client-1 to the DUT with a VendorClassID Option with <UserClassID-1>.	The DUT must transmit a DHCPv6 Reply with the address in 2001:0001:0000:0001::/64 range in response.
7.	Transmit a DHCPv6 Solicit message from Client-2.	The DUT must transmit a DHCPv6 Advertise in response using an address from Step 3.
8.	Transmit a DHCPv6 Request message from Client-2.	The DUT must transmit a DHCPv6 Reply in response using an address range from address in Step 3.
9.	Set the parameter Device.DHCPv6.Server.Pool.<Y>.VendorClassExclude=true.	
10.	Allow time for the DUT to process the set.	
11.	Transmit a DHCPv6 Solicit message from Client-1 with a VendorClassID Option in the ORO.	The DUT must transmit a DHCPv6 Advertise with the address in 2001:0001:0000:0001::/64 range in response.
12.	Transmit a DHCPv6 Request message from Client-1 to the DUT	The DUT must transmit a DHCPv6 Reply with the address in

	with a VendorClassID Option with <VendorClassID-1>.	2001:0001:0000:0001::/64 range in response.
13.	Transmit a DHCPv6 Solicit message from Client-2.	The DUT must transmit a DHCPv6 Advertise in response using an address from Step 3.
14.	Transmit a DHCPv6 Request message from Client-2.	The DUT must transmit a DHCPv6 Reply in response using an address range from address in Step 3.

## Group 4: DNS

### Scope

The following test covers DNS support of a prplOS implementation.

### Overview

The tests in this group verify the DUT properly implements DNS configuration for both WAN and LAN interfaces.

### prplOS.1.4.1: DNS Client Status

**Purpose:** Ensure the DNS Client can be enabled and disabled while reporting the correct status.

**Parameters:**

Device.DNS.Client	
Enable	true

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.DNS.Client.Status.	The value returned from the DUT must be "Enabled".

## prplOS.1.4.2: DNS Server from DHCPv4

**Purpose:** Ensure the DNS Client learns DNS Servers via DHCPv4.

**Parameters:**

Device.DNS.Client	
Enable	true

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the object Device.DNS.Client.Server.	The DUT must return the table that contains all the DNS servers. The value i is the instance that contains a Type=DHCPv4.
2.	Get the parameter Device.DNS.Client.Server.{i}.DNSServer.	The value returned from the DUT must be the IPv4 address of DNS-Server1.
3.	Get the parameter Device.DNS.Client.Server.{i}.Status.	The value returned from the DUT must be "Enabled".
4.	Set the parameter Device.DNS.Client.Server.{i}.Enabled=false.	
5.	Get the parameter Device.DNS.Client.Server.{i}.Status.	The value returned from the DUT must be "Disabled".

### prplOS.1.4.3: DNS Server from DHCPv6

**Purpose:** Ensure the DNS Client learns DNS Servers via DHCPv6.

**Parameters:**

Device.DNS.Client	
Enable	true

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the object Device.DNS.Client.Server.	The DUT must return the table that contains all the DNS servers. The value i is the instance that contains a Type=DHCPv6.
2.	Get the parameter Device.DNS.Client.Server.{i}.DNSServer.	The value returned from the DUT must be the IPv6 address of DNS-Server1.
3.	Get the parameter Device.DNS.Client.Server.{i}.Status.	The value returned from the DUT must be "Enabled".
4.	Set the parameter Device.DNS.Client.Server.{i}.Enabled=false.	
5.	Get the parameter Device.DNS.Client.Server.{i}.Status.	The value returned from the DUT must be "Disabled".

## prpIOS.1.4.4: DNS Server from Router Advertisement

**Purpose:** Ensure the DNS Client learns DNS Servers via Router Advertisements.

**Parameters:**

Device.DNS.Client	
Enable	true

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Transmit a Router Advertisement with RDNSS option containing the IPv6 address of DNS-Server1.	
2.	Get the object Device.DNS.Client.Server.	The DUT must return the table that contains all the DNS servers. The value i is the instance that contains a Type=RouterAdvertisement.
3.	Get the parameter Device.DNS.Client.Server.{i}.DNSServer.	The value returned from the DUT must be the IPv6 address of DNS-Server1.
4.	Get the parameter Device.DNS.Client.Server.{i}.Status.	The value returned from the DUT must be "Enabled".
5.	Set the parameter Device.DNS.Client.Server.{i}.Enabled=false.	
6.	Get the parameter Device.DNS.Client.Server.{i}.Status.	The value returned from the DUT must be "Disabled".

## prplOS.1.4.5: Static DNS

**Purpose:** Ensure the DNS Client is properly configured statically.

**Parameters:**

Device.DNS.Client	
Enable	true

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the object Device.DNS.Client.Server.	The DUT must return the table that contains all the DNS servers. The value i is the instance that contains a Type=Static.
2.	Set the parameter Device.DNS.Client.Server.{i}.DNSServer=<LAN Address not assigned>.	
3.	Get the parameter Device.DNS.Client.Server.{i}.DNSServer.	The value returned from the DUT must be valued as assigned in Step 2.
4.	Get the parameter Device.DNS.Client.Server.{i}.Status.	The value returned from the DUT must be "Enabled".
5.	Set the parameter Device.DNS.Client.Server.{i}.Enabled=false.	
6.	Get the parameter Device.DNS.Client.Server.{i}.Status.	The value returned from the DUT must be "Disabled".

## prplOS.1.4.6: Enable DNS Proxy

**Purpose:** Ensure the DNS Proxy can be enabled and disabled while reporting the correct status.

**Parameters:**

Device.DNS.Relay	
Enable	true

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.DNS.Relay.Enable=false.	
2.	Wait for 10 seconds.	
3.	Transmit a DNS Query from Client-1 to the DUT.	The DUT must not transmit the relayed DNS query to DNS-Server-1.
4.	Get the parameter Device.DNS.Relay.Status.	The value returned from the DUT must be "Disabled".
5.	Set the parameter Device.DNS.Relay.Enable=true.	
6.	Transmit a DNS Query from Client-1 to the DUT.	The DUT must transmit the relayed DNS query to DNS-Server-1.
7.	Get the parameter Device.DNS.Relay.Status.	The value returned from the DUT must be "Enabled".

## prplOS.1.4.7: DNS Proxy from DHCPv4

**Purpose:** Ensure the DNS Client learns DNS Proxies via DHCPv4.

**Parameters:**

Device.DNS.Relay	
Enable	true

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the object Device.DNS.Relay.Forwarding.	The DUT must return the table that contains all the DNS servers. The value i is the instance that contains a Type=DHCPv4 and Interface=<WAN>.
2.	Get the parameter Device.DNS.Relay.Forwarding.{i}.DNSServer.	The value returned from the DUT must be the IPv4 address of DNS-Server1.
3.	Get the parameter Device.DNS.Relay.Forwarding.{i}.Status.	The value returned from the DUT must be "Enabled".
4.	Set the parameter Device.DNS.Relay.Forwarding.{i}.Enabled=false.	
5.	Get the parameter Device.DNS.Relay.Forwarding.{i}.Status.	The value returned from the DUT must be "Disabled".

## prplOS.1.4.8: DNS Proxy from DHCPv6

**Purpose:** Ensure the DNS Client learns DNS Proxies via DHCPv6.

**Parameters:**

Device.DNS.Client	
Enable	true

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the object Device.DNS.Relay.Forwarding.	The DUT must return the table that contains all the DNS servers. The value i is the instance that contains a Type=DHCPv6.
2.	Get the parameter Device.DNS.Relay.Forwarding.{i}.DNSServer.	The value returned from the DUT must be the IPv6 address of DNS-Server1.
3.	Get the parameter Device.DNS.Relay.Forwarding.{i}.Status.	The value returned from the DUT must be "Enabled".
4.	Transmit a DNS Query from Client-1 to the DUT over IPv6.	The DUT must transmit the relayed DNS query to DNS-Server-1.
5.	Set the parameter Device.DNS.Relay.Forwarding.{i}.Enabled=false.	
6.	Get the parameter Device.DNS.Relay.Forwarding.{i}.Status.	The value returned from the DUT must be "Disabled".
7.	Transmit a DNS Query from Client-1 to the DUT.	The DUT must not transmit the relayed DNS query to DNS-Server-1.

## prpIOS.1.4.9: DNS Proxy from Router Advertisement

**Purpose:** Ensure the DNS Client learns DNS Proxies via Router Advertisements.

**Parameters:**

Device.DNS.Relay	
Enable	true

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Transmit a Router Advertisement with RDNSS option containing the IPv6 address of DNS-Server1.	
2.	Get the object Device.DNS.Relay.Forwarding.	The DUT must return the table that contains all the DNS servers. The value i is the instance that contains a Type=RouterAdvertisement.
3.	Get the parameter Device.DNS.Client.Forwarding.{i}.DNSServer.	The value returned from the DUT must be the IPv6 address of DNS-Server1.
4.	Get the parameter Device.DNS.Client.Forwarding.{i}.Status.	The value returned from the DUT must be "Enabled".
5.	Transmit a DNS Query from Client-1 to the DUT over IPv6.	The DUT must transmit the relayed DNS query to DNS-Server-1.
6.	Set the parameter Device.DNS.Client.Forwarding.{i}.Enabled=false.	
7.	Get the parameter Device.DNS.Client.Forwarding.{i}.Status.	The value returned from the DUT must be "Disabled".
8.	Transmit a DNS Query from Client-1 to the DUT.	The DUT must not transmit the relayed DNS query to DNS-Server-1.

## Group 5: Firewall

### **Scope**

The following test covers Firewall support of a prplOS implementations.

### **Overview**

The tests in this group verify the DUT properly implements firewall configuration and security.

### prplOS.1.5.1: Enable Firewall

**Purpose:** Ensure the Firewall can be enabled and disabled with the correct reporting status.

**Parameters:**

Device.Firewall	
Enable	true
Config	Policy
PolicyLevel	Device.Firewall.Level.Medium.

Device.Firewall.Level.Medium.	
DefaultPolicy	Drop
Policies	Device.Firewall.Policy.WAN2LAN_medium

Device.Firewall.Policy.WAN2LAN_medium	
Chain	Device.Firewall.Chain.Medium
Enable	true

Device.Firewall.Chain.Medium	
Enable	true

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Transmit traffic from Host-1 to Client-1.	The DUT must NOT forward traffic from Host-1 to Client-1.

2.	Set the parameter Device.Firewall.Enabled=false.	
3.	Transmit traffic from Host-1 to Client-1.	The DUT must forward traffic from Host-1 to Client-1.

## prplOS.1.5.2: Firewall LastChange

**Purpose:** Ensure the Firewall reports the LastChange time correctly.

**Parameters:**

Device.Firewall	
Enable	true
Config	Policy
PolicyLevel	Device.Firewall.Level.Medium.

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.Firewall.LastChange	The DUT returns a dateTime since the last operational state change.
2.	Set the parameter Device.Firewall.Enabled=false.	
3.	Get the parameter Device.Firewall.LastChange	The DUT returns a value that is a different later time then the value returned in Step 1.

### prplOS.1.5.3: Default Policy

**Purpose:** Ensure the Firewall sets the DefaultPolicy.

**Parameters:**

Device.Firewall	
Enable	true
Config	Policy
PolicyLevel	Device.Firewall.Level.Medium.

Device.Firewall.Level.Medium.	
DefaultPolicy	Drop
Policies	Device.Firewall.Policy.WAN2LAN_medium

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Transmit traffic from Host-1 to Client-1.	The DUT must NOT forward traffic from Host-1 to Client-1.
2.	Set the parameter Device.Firewall.Level.Medium.Default Policy=Accept	
3.	Transmit traffic from Host-1 to Client-1.	The DUT must forward traffic from Host-1 to Client-1.

## prplOS.1.5.4: Enable Firewall Policies

**Purpose:** Ensure the DUT properly enables firewall policies.

**Parameters:**

Device.Firewall	
Enable	true
Config	Policy
PolicyLevel	Device.Firewall.Level.Medium.

Device.Firewall.Level.Medium.	
DefaultPolicy	Drop
Policies	Device.Firewall.Policy.IPV6_WAN2LAN_medium

Device.Firewall.Policy.IPV6_WAN2LAN_medium	
Chain	Device.Firewall.Chain.IPV6_Medium
Enable	true

Device.Firewall.Chain.IPV6_Medium	
Enable	true

Device.Firewall.Chain.IPV6_Medium.Rule.<X>	
Enable	true
Target	Accept
Order	2

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.Firewall.Chain.IPV6_Medium.Rule.<X> object with the parameters specified in the table above.	
2.	Transmit traffic from Host-1 to Client-1.	The DUT must forward traffic from Host-1 to Client-1.
3.	Get the parameter Device.Firewall.Policy.IPV6_WAN2LAN_medium.Status	The value returned from the DUT must be "Enabled".
4.	Set the parameter Device.Firewall.Policy.IPV6_WAN2LAN_medium.Enable=false	
5.	Transmit traffic from Host-1 to Client-1.	The DUT must NOT forward traffic from Host-1 to Client-1.
6.	Get the parameter Device.Firewall.Policy.IPV6_WAN2LAN_medium.Status	The value returned from the DUT must be "Disabled".

## prplOS.1.5.5: Enable Firewall Chain

**Purpose:** Ensure the DUT properly enables firewall chains.

**Parameters:**

Device.Firewall	
Enable	true
Config	Policy
PolicyLevel	Device.Firewall.Level.Medium.

Device.Firewall.Level.Medium.	
DefaultPolicy	Drop
Policies	Device.Firewall.Policy.IPV6_WAN2LAN_medium

Device.Firewall.Policy.IPV6_WAN2LAN_medium	
Chain	Device.Firewall.Chain.IPV6_Medium
Enable	true

Device.Firewall.Chain.IPV6_Medium	
Enable	true

Device.Firewall.Chain.IPV6_Medium.Rule.<X>	
Enable	true
Target	Accept
Order	2

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

<b>Step</b>	<b>Action</b>	<b>Expected Behavior</b>
1.	Add a new Device.Firewall.Chain.IPV6_Medium.Rule.<X> object with the parameters specified in the table above.	
2.	Transmit traffic from Host-1 to Client-1.	The DUT must forward traffic from Host-1 to Client-1.
3.	Set the parameter Device.Firewall.Chain.IPV6_Medium.Enable=false.	
4.	Transmit traffic from Host-1 to Client-1.	The DUT must NOT forward traffic from Host-1 to Client-1.

## prplOS.1.5.6: Enable Firewall Rules

**Purpose:** Ensure the DUT properly enables firewall rules.

**Parameters:**

Device.Firewall	
Enable	true
Config	Policy
PolicyLevel	Device.Firewall.Level.Medium.

Device.Firewall.Level.Medium.	
DefaultPolicy	Drop
Policies	Device.Firewall.Policy.IPV6_WAN2LAN_medium

Device.Firewall.Policy.IPV6_WAN2LAN_medium	
Chain	Device.Firewall.Chain.IPV6_Medium
Enable	true

Device.Firewall.Chain.IPV6_Medium	
Enable	true

Device.Firewall.Chain.IPV6_Medium.Rule.<X>	
Enable	true
Target	Accept
Order	2

Device.Firewall.Chain.IPV6_Medium.Rule.<Y>	
Enable	true
Target	Reject
Order	3

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.Firewall.Chain.IPV6_Medium.Rule.<X> object with the parameters specified in the table above.	
2.	Add a new Device.Firewall.Chain.IPV6_Medium.Rule.<Y> object with the parameters specified in the table above.	
3.	Transmit an ICMP Ping from Host-1 to Client-1.	The DUT must forward ICMP Ping from Host-1 to Client-1.
4.	Get the parameter Device.Firewall.Chain.IPv6_Medium.Rule.<X>.Status	The value returned from the DUT must be "Enabled".
5.	Get the parameter Device.Firewall.Chain.IPV6_Medium.Rule.<Y>.Status	The value returned from the DUT must be "Enabled".
6.	Set the parameter Device.Firewall.Chain.IPV6_Medium.Rule.<X>.Enable=false	
7.	Transmit an ICMP Ping from Host-1 to Client-1.	The DUT must NOT forward traffic from Host-1 to Client-1.
8.	Get the parameter Device.Firewall.Chain.IPv6_Medium.Rule	The value returned from the DUT must be "Disabled".

	e.<X>.Status	
--	--------------	--

## prplOS.1.5.7: Firewall Rules Protocol

**Purpose:** Ensure the DUT properly implements a firewall based on protocol.

**Parameters:**

Device.Firewall	
Enable	true
Config	Policy
PolicyLevel	Device.Firewall.Level.Medium.

Device.Firewall.Level.Medium.	
DefaultPolicy	Drop
Policies	Device.Firewall.Policy.IPV6_WAN2LAN_medium

Device.Firewall.Policy.IPV6_WAN2LAN_medium	
Chain	Device.Firewall.Chain.IPV6_Medium
Enable	true

Device.Firewall.Chain.IPV6_Medium	
Enable	true

Device.Firewall.Chain.IPV6_Medium.Rule.<X>	
Enable	true
Target	Accept
Order	1

Protocol	6
----------	---

Device.Firewall.Chain.Medium.Rule.<Y>	
Enable	true
Target	Reject
Order	2
Protocol	-1

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.Firewall.Chain.Medium.Rule.<X> object with the parameters specified in the table above.	
2.	Add a new Device.Firewall.Chain.Medium.Rule.<Y> object with the parameters specified in the table above.	
3.	Transmit TCP traffic from Host-1 to Client-1.	The DUT must forward TCP traffic from Host-1 to Client-1.
4.	Transmit UDP traffic from Host-1 to Client-1.	The DUT must not forward UDP traffic from Host-1 to Client-1.
5.	Set the parameter Device.Firewall.Chain.Medium.Rule.<X>.Protocol=17	
6.	Transmit TCP traffic from Host-1 to Client-1.	The DUT must not forward TCP traffic from Host-1 to Client-1.
7.	Transmit UDP traffic from Host-1 to	The DUT must forward UDP traffic

	Client-1.	from Host-1 to Client-1.
--	-----------	--------------------------

## prplOS.1.5.8: Firewall Rules based on IP Version, IPv4 Policy

**Purpose:** Ensure the DUT properly implements a firewall based on IP version.

**Parameters:**

Device.Firewall	
Enable	true
Config	Policy
PolicyLevel	Device.Firewall.Level.Medium.

Device.Firewall.Level.Medium.	
DefaultPolicy	Drop
Policies	Device.Firewall.Policy.WAN2LAN_medium

Device.Firewall.Policy.WAN2LAN_medium	
Chain	Device.Firewall.Chain.Medium
Enable	true
IPVersion	4

Device.Firewall.Chain.Medium	
Enable	true

Device.Firewall.Chain.Medium.Rule.<X>	
Enable	true
Target	Accept
Order	1

IPVersion	4
-----------	---

Device.Firewall.Chain.Medium.Rule.<Y>	
Enable	true
Target	Reject
Order	2

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.Firewall.Chain.Medium.Rule.<X> object with the parameters specified in the table above.	
2.	Add a new Device.Firewall.Chain.Medium.Rule.<Y> object with the parameters specified in the table above.	
3.	Transmit IPv4 traffic from Host-1 to Client-1.	The DUT must forward IPv4 traffic from Host-1 to Client-1.
4.	Set the parameter Device.Firewall.Chain.Medium.Rule.<X>.IPVersion=6.	
5.	Transmit IPv4 traffic from Host-1 to Client-1.	The DUT must not forward IPv4 traffic from Host-1 to Client-1.

## prplOS.1.5.9: Firewall Rules based on IP Version, IPv6 Policy

**Purpose:** Ensure the DUT properly implements a firewall based on IP version.

**Parameters:**

Device.Firewall	
Enable	true
Config	Policy
PolicyLevel	Device.Firewall.Level.Medium.

Device.Firewall.Level.Medium.	
DefaultPolicy	Drop
Policies	Device.Firewall.Policy.IPV6_WAN2LAN_medium

Device.Firewall.Policy.IPV6_WAN2LAN_medium	
Chain	Device.Firewall.IPV6_Chain.Medium
Enable	true
IPVersion	6

Device.Firewall.Chain.IPV6_Medium	
Enable	true

Device.Firewall.Chain.IPV6_Medium.Rule.<X>	
Enable	true
Target	Accept

Order	1
IPVersion	6

Device.Firewall.Chain.IPV6_Medium.Rule.<Y>	
Enable	true
Target	Reject
Order	2

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.Firewall.Chain.Medium.Rule.<X> object with the parameters specified in the table above.	
2.	Add a new Device.Firewall.Chain.Medium.Rule.<Y> object with the parameters specified in the table above.	
3.	Transmit IPv6 traffic from Host-1 to Client-1.	The DUT must forward IPv6 traffic from Host-1 to Client-1.
4.	Set the parameter Device.Firewall.Chain.Medium.Rule.<X>.IPVersion=4.	
5.	Transmit IPv6 traffic from Host-1 to Client-1.	The DUT must not forward IPv6 traffic from Host-1 to Client-1.

## prplOS.1.5.10: Firewall Rules based on IPv4 Source Address

**Purpose:** Ensure the DUT properly implements a firewall based on IPv4 source address.

**Parameters:**

Device.Firewall	
Enable	true
Config	Policy
PolicyLevel	Device.Firewall.Level.Medium.

Device.Firewall.Level.Medium.	
DefaultPolicy	Drop
Policies	Device.Firewall.Policy.WAN2LAN_medium

Device.Firewall.Policy.WAN2LAN_medium	
Chain	Device.Firewall.Chain.Medium
Enable	true

Device.Firewall.Chain.Medium	
Enable	true

Device.Firewall.Chain.Medium.Rule.<X>	
Enable	true
Target	Accept
Order	1
SourceIP	<Host-1 IPv4 Address>

IPVersion	4
-----------	---

Device.Firewall.Chain.Medium.Rule.<Y>	
Enable	true
Target	Reject
Order	2

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.Firewall.Chain.Medium.Rule.<X> object with the parameters specified in the table above.	
2.	Add a new Device.Firewall.Chain.Medium.Rule.<Y> object with the parameters specified in the table above.	
3.	Transmit IPv4 traffic from Host-1 to Client-1.	The DUT must forward IPv4 traffic from Host-1 to Client-1.
4.	Transmit IPv4 traffic from Host-2 to Client-1.	The DUT must not forward IPv4 traffic from Host-2 to Client-1.
5.	Set the parameter Device.Firewall.Chain.Medium.Rule.<X>.SourceIP=<Host-2 IPv4 Address>.	
6.	Transmit IPv4 traffic from Host-1 to Client-1.	The DUT must not forward IPv4 traffic from Host-1 to Client-1.
7.	Transmit IPv4 traffic from Host-2 to Client-1.	The DUT must forward IPv4 traffic from Host-2 to Client-1.

## prpIOS.1.5.11: Firewall Rules based on IPv6 Source Address

**Purpose:** Ensure the DUT properly implements a firewall based on IPv6 source address.

**Parameters:**

Device.Firewall	
Enable	true
Config	Policy
PolicyLevel	Device.Firewall.Level.Medium.

Device.Firewall.Level.Medium.	
DefaultPolicy	Drop
Policies	Device.Firewall.Policy.IPV6_WAN2LAN_medium

Device.Firewall.Policy.IPV6_WAN2LAN_medium	
Chain	Device.Firewall.Chain.IPV6_Medium
Enable	true

Device.Firewall.Chain.IPV6_Medium	
Enable	true

Device.Firewall.Chain.IPV6_Medium.Rule.<X>	
Enable	true
Target	Accept
Order	1

SourceIP	<Host-1 IPv6 Address>
IPVersion	6

Device.Firewall.Chain.IPV6_Medium.Rule.<Y>	
Enable	true
Target	Reject
Order	2

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.Firewall.Chain.Medium.Rule.<X> object with the parameters specified in the table above.	
2.	Add a new Device.Firewall.Chain.Medium.Rule.<Y> object with the parameters specified in the table above.	
3.	Transmit IPv6 traffic from Host-1 to Client-1.	The DUT must forward IPv6 traffic from Host-1 to Client-1.
4.	Transmit IPv6 traffic from Host-2 to Client-1.	The DUT must not forward IPv6 traffic from Host-2 to Client-1.
5.	Set the parameter Device.Firewall.Chain.Medium.Rule.<X>.SourceIP=<Host-2 IPv6 Address>.	
6.	Transmit IPv6 traffic from Host-1 to Client-1.	The DUT must not forward IPv6 traffic from Host-1 to Client-1.

7.	Transmit IPv6 traffic from Host-2 to Client-1.	The DUT must forward IPv6 traffic from Host-2 to Client-1.
----	--	--

## prplOS.1.5.12: Firewall Rules based on IPv4 Destination Address

**Purpose:** Ensure the DUT properly implements a firewall based on IPv4 destination address.

**Parameters:**

Device.Firewall	
Enable	true
Config	Policy
PolicyLevel	Device.Firewall.Level.Medium.

Device.Firewall.Level.Medium.	
DefaultPolicy	Drop
Policies	Device.Firewall.Policy.WAN2LAN_medium

Device.Firewall.Policy.WAN2LAN_medium	
Chain	Device.Firewall.Chain.Medium
Enable	true

Device.Firewall.Chain.Medium	
Enable	true

Device.Firewall.Chain.Medium.Rule.<X>	
Enable	true
Target	Accept
Order	1
DestIP	<Client-1 IPv4 Address>

IPVersion	4
-----------	---

Device.Firewall.Chain.Medium.Rule.<Y>	
Enable	true
Target	Reject
Order	2

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.Firewall.Chain.Medium.Rule.<X> object with the parameters specified in the table above.	
2.	Add a new Device.Firewall.Chain.Medium.Rule.<Y> object with the parameters specified in the table above.	
3.	Transmit IPv4 traffic from Host-1 to Client-1.	The DUT must forward IPv4 traffic from Host-1 to Client-1.
4.	Transmit IPv4 traffic from Host-1 to Client-2.	The DUT must not forward IPv4 traffic from Host-1 to Client-2.
5.	Set the parameter Device.Firewall.Chain.Medium.Rule.<X>.SourceIP=<Host-2 IPv4 Address>.	
6.	Transmit IPv4 traffic from Host-1 to Client-1.	The DUT must not forward IPv4 traffic from Host-1 to Client-1.
7.	Transmit IPv4 traffic from Host-1 to Client-2.	The DUT must forward IPv4 traffic from Host-1 to Client-2.

## prplOS.1.5.13: Firewall Rules based on IPv6 Destination Address

**Purpose:** Ensure the DUT properly implements a firewall based on IPv6 destination address.

**Parameters:**

Device.Firewall	
Enable	true
Config	Policy
PolicyLevel	Device.Firewall.Level.Medium.

Device.Firewall.Level.Medium.	
DefaultPolicy	Drop
Policies	Device.Firewall.Policy.IPV6_WAN2LAN_medium

Device.Firewall.Policy.IPV6_WAN2LAN_medium	
Chain	Device.Firewall.Chain.IPV6_Medium
Enable	true

Device.Firewall.Chain.IPV6_Medium	
Enable	true

Device.Firewall.Chain.IPV6_Medium.Rule.<X>	
Enable	true
Target	Accept
Order	1

SourceIP	<Host-1 IPv6 Address>
IPVersion	6

Device.Firewall.Chain.IPV6_Medium.Rule.<Y>	
Enable	true
Target	Reject
Order	2

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.Firewall.Chain.Medium.Rule.<X> object with the parameters specified in the table above.	
2.	Add a new Device.Firewall.Chain.Medium.Rule.<Y> object with the parameters specified in the table above.	
3.	Transmit IPv6 traffic from Host-1 to Client-1.	The DUT must forward IPv6 traffic from Host-1 to Client-1.
4.	Transmit IPv6 traffic from Host-1 to Client-2.	The DUT must not forward IPv6 traffic from Host-1 to Client-2.
5.	Set the parameter Device.Firewall.Chain.Medium.Rule.<X>.SourceIP=<Host-2 IPv6 Address>.	
6.	Transmit IPv6 traffic from Host-1 to Client-1.	The DUT must not forward IPv6 traffic from Host-1 to Client-1.

7.	Transmit IPv6 traffic from Host-1 to Client-2.	The DUT must forward IPv6 traffic from Host-1 to Client-2.
----	--	--

## prplOS.1.5.14: Firewall Rules based on TCP Source Port

**Purpose:** Ensure the DUT properly implements a firewall based on source port.

**Parameters:**

Device.Firewall	
Enable	true
Config	Policy
PolicyLevel	Device.Firewall.Level.Medium.

Device.Firewall.Level.Medium.	
DefaultPolicy	Drop
Policies	Device.Firewall.Policy.IPV6_WAN2LAN_medium

Device.Firewall.Policy.IPV6_WAN2LAN_medium	
Chain	Device.Firewall.Chain.IPV6_Medium
Enable	true

Device.Firewall.Chain.IPV6_Medium	
Enable	true

Device.Firewall.Chain.IPV6_Medium.Rule.<X>	
Enable	true
Target	Accept
Order	1

SourcePort	49600
Protocol	6

Device.Firewall.Chain.IPV6_Medium.Rule.<Y>	
Enable	true
Target	Reject
Order	2

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.Firewall.Chain.Medium.Rule.<X> object with the parameters specified in the table above.	
2.	Add a new Device.Firewall.Chain.Medium.Rule.<Y> object with the parameters specified in the table above.	
3.	Transmit TCP traffic with a source port of 49600 from Host-1 to Client-1.	The DUT must forward UDP traffic from Host-1 to Client-1.
4.	Transmit TCP traffic with a source port of 51000 from Host-1 to Client-1.	The DUT must not forward UDP traffic from Host-1 to Client-1.
5.	Set the parameter Device.Firewall.Chain.Medium.Rule.<X>.SourcePort=51000.	
6.	Transmit TCP traffic with a source port of 49600 from Host-1 to Client-1.	The DUT must not forward UDP traffic from Host-1 to Client-1.

7.	Transmit TCP traffic with a source port of 51000 from Host-1 to Client-1.	The DUT must forward UDP traffic from Host-1 to Client-1.
----	---	---

## prplOS.1.5.15: Firewall Rules based on UDP Source Port

**Purpose:** Ensure the DUT properly implements a firewall based on source port.

**Parameters:**

Device.Firewall	
Enable	true
Config	Policy
PolicyLevel	Device.Firewall.Level.Medium.

Device.Firewall.Level.Medium.	
DefaultPolicy	Drop
Policies	Device.Firewall.Policy.IPV6_WAN2LAN_medium

Device.Firewall.Policy.IPV6_WAN2LAN_medium	
Chain	Device.Firewall.Chain.IPV6_Medium
Enable	true

Device.Firewall.Chain.IPV6_Medium	
Enable	true

Device.Firewall.Chain.IPV6_Medium.Rule.<X>	
Enable	true
Target	Accept
Order	1

SourcePort	49600
Protocol	17

Device.Firewall.Chain.IPV6_Medium.Rule.<Y>	
Enable	true
Target	Reject
Order	2

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.Firewall.Chain.Medium.Rule.<X> object with the parameters specified in the table above.	
2.	Add a new Device.Firewall.Chain.Medium.Rule.<Y> object with the parameters specified in the table above.	
3.	Transmit UDP traffic with a source port of 49600 from Host-1 to Client-1.	The DUT must forward UDP traffic from Host-1 to Client-1.
4.	Transmit UDP traffic with a source port of 51000 from Host-1 to Client-1.	The DUT must not forward UDP traffic from Host-1 to Client-1.
5.	Set the parameter Device.Firewall.Chain.Medium.Rule.<X>.SourcePort=51000.	
6.	Transmit UDP traffic with a source port of 49600 from Host-1 to Client-1.	The DUT must not forward UDP traffic from Host-1 to Client-1.

7.	Transmit UDP traffic with a source port of 51000 from Host-1 to Client-1.	The DUT must forward UDP traffic from Host-1 to Client-1.
----	---	---

### prplOS.1.5.16: Firewall Rules based on TCP Destination Port

**Purpose:** Ensure the DUT properly implements a firewall based on the destination port.

**Parameters:**

Device.Firewall	
Enable	true
Config	Policy
PolicyLevel	Device.Firewall.Level.Medium.

Device.Firewall.Level.Medium.	
DefaultPolicy	Drop
Policies	Device.Firewall.Policy.IPV6_WAN2LAN_medium

Device.Firewall.Policy.IPV6_WAN2LAN_medium	
Chain	Device.Firewall.Chain.IPV6_Medium
Enable	true

Device.Firewall.Chain.IPV6_Medium	
Enable	true

Device.Firewall.Chain.IPV6_Medium.Rule.<X>	
Enable	true

Target	Accept
Order	1
DestPort	80
Protocol	6

Device.Firewall.Chain.IPV6_Medium.Rule.<Y>	
Enable	true
Target	Reject
Order	2

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.Firewall.Chain.Medium.Rule.<X> object with the parameters specified in the table above.	
2.	Add a new Device.Firewall.Chain.Medium.Rule.<Y> object with the parameters specified in the table above.	
3.	Transmit TCP port 80 traffic from Host-1 to Client-1.	The DUT must forward HTTP traffic from Host-1 to Client-1.
4.	Transmit TCP port 443 from Host-1 to Client-1.	The DUT must not forward HTTPS traffic from Host-1 to Client-1.
5.	Set the parameter Device.Firewall.Chain.Medium.Rule.<X>	

	.SourcePort=443.	
6.	Transmit TCP port 80 traffic from Host-1 to Client-1.	The DUT must not forward HTTP traffic from Host-1 to Client-1.
7.	Transmit TCP port 443 from Host-1 to Client-1.	The DUT must forward HTTPS traffic from Host-1 to Client-1.

## prpIOS.1.5.17: Firewall Rules based on UDP Destination Port

**Purpose:** Ensure the DUT properly implements a firewall based on the destination port.

**Parameters:**

Device.Firewall	
Enable	true
Config	Policy
PolicyLevel	Device.Firewall.Level.Medium.

Device.Firewall.Level.Medium.	
DefaultPolicy	Drop
Policies	Device.Firewall.Policy.IPV6_WAN2LAN_medium

Device.Firewall.Policy.IPV6_WAN2LAN_medium	
Chain	Device.Firewall.Chain.IPV6_Medium
Enable	true

Device.Firewall.Chain.IPV6_Medium	
Enable	true

Device.Firewall.Chain.IPV6_Medium.Rule.<X>	
Enable	true
Target	Accept
Order	1

DestPort	80
Protocol	17

Device.Firewall.Chain.IPV6_Medium.Rule.<Y>	
Enable	true
Target	Reject
Order	2

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.Firewall.Chain.Medium.Rule.<X> object with the parameters specified in the table above.	
2.	Add a new Device.Firewall.Chain.Medium.Rule.<Y> object with the parameters specified in the table above.	
3.	Transmit UDP port 80 traffic from Host-1 to Client-1.	The DUT must forward HTTP traffic from Host-1 to Client-1.
4.	Transmit UDP port 443 from Host-1 to Client-1.	The DUT must not forward HTTPS traffic from Host-1 to Client-1.
5.	Set the parameter Device.Firewall.Chain.Medium.Rule.<X>.SourcePort=443.	
6.	Transmit UDP port 80 traffic from Host-1 to Client-1.	The DUT must not forward HTTP traffic from Host-1 to Client-1.

7.	Transmit UDP port 443 from Host-1 to Client-1.	The DUT must forward HTTPS traffic from Host-1 to Client-1.
----	--	---

## prplOS.1.5.18: Firewall Rules based on Source Mac

**Purpose:** Ensure the DUT properly implements a firewall based on the Source MAC address.

**Parameters:**

Device.Firewall	
Enable	true
Config	Policy
PolicyLevel	Device.Firewall.Level.Medium.

Device.Firewall.Level.Medium.	
DefaultPolicy	Drop
Policies	Device.Firewall.Policy.WAN2LAN_medium

Device.Firewall.Policy.WAN2LAN_medium	
Chain	Device.Firewall.Chain.Medium
Enable	true

Device.Firewall.Chain.Medium	
Enable	true

Device.Firewall.Chain.Medium.Rule.<X>	
Enable	true
Target	Accept
Order	1
SourceMAC	<Host-1 Source MAC>

Device.Firewall.Chain.Medium.Rule.<Y>	
Enable	true
Target	Reject
Order	2

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.Firewall.Chain.Medium.Rule.<X> object with the parameters specified in the table above.	
2.	Add a new Device.Firewall.Chain.Medium.Rule.<Y> object with the parameters specified in the table above.	
3.	Transmit traffic from Host-1 to Client-1.	The DUT must forward traffic from Host-1 to Client-1.
4.	Transmit traffic from Host-2 to Client-1.	The DUT must not forward traffic from Host-2 to Client-1.
5.	Set the parameter Device.Firewall.Chain.Medium.Rule.<X>.SourceMAC=<Host-2 MAC address>	
6.	Transmit traffic from Host-1 to Client-1.	The DUT must not forward traffic from Host-1 to Client-1.
7.	Transmit traffic from Host-2 to Client-1.	The DUT must forward traffic from Host-2 to Client-1.

## prplOS.1.5.19: Firewall Rules based on DSCP

**Purpose:** Ensure the DUT properly implements a firewall based on the DSCP value.

**Parameters:**

Device.Firewall	
Enable	true
Config	Policy
PolicyLevel	Device.Firewall.Level.Medium.

Device.Firewall.Level.Medium.	
DefaultPolicy	Drop
Policies	Device.Firewall.Policy.WAN2LAN_medium

Device.Firewall.Policy.WAN2LAN_medium	
Chain	Device.Firewall.Chain.Medium
Enable	true

Device.Firewall.Chain.Medium	
Enable	true

Device.Firewall.Chain.Medium.Rule.<X>	
Enable	true
Target	Accept
Order	1
DSCP	40

Device.Firewall.Chain.Medium.Rule.<Y>	
Enable	true
Target	Reject
Order	2

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.Firewall.Chain.Medium.Rule.<X> object with the parameters specified in the table above.	
2.	Add a new Device.Firewall.Chain.Medium.Rule.<Y> object with the parameters specified in the table above.	
3.	Transmit UDP traffic with DSCP-40 from Host-1 to Client-1.	The DUT must forward UDP traffic from Host-1 to Client-1.
4.	Transmit UDP traffic with DSCP-41 from Host-1 to Client-1.	The DUT must forward UDP traffic from Host-1 to Client-1.
5.	Transmit UDP traffic with DSCP-32 from Host-1 to Client-1.	The DUT must not forward UDP traffic from Host-1 to Client-1.
6.	Transmit UDP traffic with DSCP-33 from Host-1 to Client-1.	The DUT must not forward UDP traffic from Host-1 to Client-1.
7.	Set the parameter Device.Firewall.Chain.Medium.Rule.<X>.DSCP=32	
8.	Transmit UDP traffic with DSCP-40 from Host-1 to Client-1.	The DUT must not forward UDP traffic from Host-1 to Client-1.
9.	Transmit UDP traffic with DSCP-41 from Host-1 to Client-1.	The DUT must not forward UDP traffic from Host-1 to Client-1.

10.	Transmit UDP traffic with DSCP-32 from Host-1 to Client-1.	The DUT must forward UDP traffic from Host-1 to Client-1.
11.	Transmit UDP traffic with DSCP-33 from Host-1 to Client-1.	The DUT must forward UDP traffic from Host-1 to Client-1.

## Group 6: IP Interfaces

### Scope

The following test covers IPv4 and IPv6 addressing in a prplOS implementations.

### Overview

The tests in this group verify the DUT properly implements IP addressing, subnetting/prefixing, and statistics for both WAN and LAN.

### prplOS.1.6.1: IPv4 Status

**Purpose:** Ensure that DUT properly reports IPv4.

**Parameters:**

Device.IP.	
IPv4Capable	
IPv4Enable	
IPv4 Status	

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.IP.IPv4Capable.	The value returned from the DUT must be true.
2.	Get the parameter Device.IP.IPv4Enable.	The value returned from the DUT must be true.
3.	Get the parameter Device.IP.IPv4Status	The DUT must return a value of Enabled for the parameter.

## prplOS.1.6.2: IPv6 Status

**Purpose:** Ensure that DUT properly reports IPv6.

**Parameters:**

Device.IP.	
IPv6Capable	
IPv6Enable	
IPv6Status	

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.IP.IPv6Capable.	The value returned from the DUT must be true.
2.	Get the parameter Device.IP.IPv6Enable.	The value returned from the DUT must be true.
3.	Get the parameter Device.IP.IPv6Status	The DUT must return a value of Enabled for the parameter.

### prplOS.1.6.3: IPv4 WAN Status

**Purpose:** Ensure that DUT properly reports the WAN IPv4 status.

**Parameters:**

Device.IP.Interface.<WAN>.	
Enable	
IPv4Enable	
Status	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.IP.Interface.<WAN>.Enable	The value returned from the DUT must be true.
2.	Get the parameter Device.IP.Interface.<WAN>.Status	The DUT must return a value of Up for the parameter.
3.	Get the parameter Device.IP.Interface.<WAN>.IPv4Enable	The value returned from the DUT must be true.

## prplOS.1.6.4: IPv6 WAN Status

**Purpose:** Ensure that DUT properly reports the WAN IPv6 status.

**Parameters:**

Device.IP.Interface.<WAN>.	
Enable	
IPv6Enable	
Status	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.IP.Interface.<WAN>.Enable	The value returned from the DUT must be true.
2.	Get the parameter Device.IP.Interface.<WAN>.Status	The DUT must return a value of Up for the parameter.
3.	Get the parameter Device.IP.Interface.<WAN>.IPv6Enable	The value returned from the DUT must be true.

### prplOS.1.6.5: IPv4 WAN Address

**Purpose:** Ensure that DUT properly reports the WAN IPv4 address.

**Parameters:**

Device.IP.Interface.<WAN>.IPv4Address.{i}.	
Enable	
IPAddress	
Status	
SubnetMask	
AddressingType	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.IP.Interface.<WAN>.IPv4Address.<primary>.Enable	The value returned from the DUT must be true.
2.	Get the parameter Device.IP.Interface.<WAN>.IPv4Address.<primary>.Status	The DUT must return a value of Enabled for the parameter.
3.	Get the parameter Device.IP.Interface.<WAN>.IPv4Address.<primary>.IPAddress	The DUT must return a value of IPv4 address of the WAN interface for the parameter.
4.	Get the parameter Device.IP.Interface.<WAN>.IPv4Address.<primary>.SubnetMask	The DUT must return a value of IPv4 subnet mask of the WAN interface for the parameter.
5.	Device.IP.Interface.<WAN>.IPv4Address.<primary>.AddressingType	The DUT must return a value of DHCP for the parameter.

## prplOS.1.6.6: IPv6 Link Local WAN Address

**Purpose:** Ensure that DUT properly reports the WAN IPv6 link-local address.

**Parameters:**

Device.IP.Interface.<WAN>.IPv6Address.<LLA>.	
Enable	
IPAddress	<IPv6 Link Local Address>
IPAddressStatus	
Status	
Origin	
PreferredLifetime	
ValidLifetime	
Anycast	

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.IP.Interface.<WAN>.IPv6Address.<LLA>.Enable	The value returned from the DUT must be true.
2.	Get the parameter Device.IP.Interface.<WAN>.IPv6Address.<LLA>.Status	The DUT must return a value of Enabled for the parameter.
3.	Get the parameter Device.IP.Interface.<WAN>.IPv6Address.<LLA>.IPAddress	The DUT must return a value of IPv6 link local address of the WAN interface for the parameter.
4.	Get the parameter Device.IP.Interface.<WAN>.IPv6Address.<LLA>.IPAddressStatus	The DUT must return a value of Preferred for the parameter.

5.	Get the parameter Device.IP.Interface.<WAN>.IPv6Address.<LLA>.Origin	The DUT must return a value of AutoConfigured for the parameter.
6.	Device.IP.Interface.<WAN>.IPv6Address.<LLA>.PreferredLifetime	The DUT must return a value of 9999-12-31T23:59:59Z for the parameter.
7.	Device.IP.Interface.<WAN>.IPv6Address.<LLA>.ValidLifetime	The DUT must return a value of 9999-12-31T23:59:59Z for the parameter.
8.	Device.IP.Interface.<WAN>.IPv6Address.<LLA>.Anycast	The value returned from the DUT must be false.

## prplOS.1.6.7: IPv6 Global WAN Address

**Purpose:** Ensure that DUT properly reports the WAN IPv6 global address.

**Parameters:**

Device.IP.Interface.<WAN>.IPv6Address.<GUA_RA/DHCP>.	
Enable	
IPAddress	<IPv6 Global Unicast Address>
IPAddressStatus	
Status	
Origin	
PreferredLifetime	
ValidLifetime	
Anycast	
Prefix	<IPv6 Prefix from Router Advertisement>

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part. The alias GUA\_RA is used when using SLAAC for WAN addressing. The alias DHCP is used when using DHCPv6 for WAN addressing.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.IP.Interface.<WAN>.IPv6Address.<GUA_RA/DHCP>.Enable	The value returned from the DUT must be true.
2.	Get the parameter Device.IP.Interface.<WAN>.IPv6Address.<GUA_RA/DHCP>.Status	The DUT must return a value of Enabled for the parameter.
3.	Get the parameter Device.IP.Interface.<WAN>.IPv6Address	The DUT must return a value of IPv6 link local address of the WAN

	ess.<GUA_RA/DHCP>.IPAddress	interface for the parameter.
4.	Get the parameter Device.IP.Interface.<WAN>.IPv6Address.ess.<GUA_RA/DHCP>.IPAddressStatus	The DUT must return a value of Preferred for the parameter.
5.	Get the parameter Device.IP.Interface.<WAN>.IPv6Address.ess.<GUA_RA/DHCP>.Origin	The DUT must return a value of AutoConfigured or DHCPv6 for the parameter based on the configuration.
6.	Device.IP.Interface.<WAN>.IPv6Address.<GUA_RA/DHCP>.PreferredLifetime	The DUT must return a value equal to the time when it will expire based on the time supplied from Router Advertisements or DHCPv6.
7.	Device.IP.Interface.<WAN>.IPv6Address.<GUA_RA/DHCP>.ValidLifetime	The DUT must return a value equal to the time when it will expire based on the time supplied from Router Advertisements or DHCPv6.
8.	Device.IP.Interface.<WAN>.IPv6Address.<GUA_RA/DHCP>.Anycast	The value returned from the DUT must be false.

## prplOS.1.6.8: IPv6 WAN Router Advertisement Prefix

**Purpose:** Ensure that DUT properly reports the WAN IPv6 Router Advertisement prefix.

**Parameters:**

Device.IP.Interface.<WAN>.IPv6Prefix.<GUA_RA>.	
Enable	
Prefix	<IPv6 Address prefix>
Status	
Origin	
PreferredLifetime	
ValidLifetime	
PrefixStatus	
OnLink	
Autonomous	
StaticType	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.IP.Interface.<WAN>.IPv6Address.<GUA_RA>.Enable	The value returned from the DUT must be true.
2.	Get the parameter Device.IP.Interface.<WAN>.IPv6Address.<GUA_RA>.Status	The DUT must return a value of Enabled for the parameter.
3.	Get the parameter Device.IP.Interface.<WAN>.IPv6Address.<GUA_RA>.Prefix	The DUT must return a value of IPv6 prefix address of the WAN interface for the parameter.

4.	Get the parameter Device.IP.Interface.<WAN>.IPv6Address.<GUA_RA>.Origin	The DUT must return a value of RouterAdvertisement for the parameter based on the configuration.
5.	Device.IP.Interface.<WAN>.IPv6Address.<GUA_RA>.PreferredLifetime	The DUT must return a value equal to the time when it will expire based on the preferred lifetime supplied from Router Advertisement.
6.	Device.IP.Interface.<WAN>.IPv6Address.<GUA_RA>.ValidLifetime	The DUT must return a value equal to the time when it will expire based on the valid lifetime supplied from Router Advertisement.
7.	Device.IP.Interface.<WAN>.IPv6Address.<GUA_RA>.PrefixStatus	The value returned from the DUT must be Preferred.
8.	Device.IP.Interface.<WAN>.IPv6Address.<GUA_RA>.OnLink	The value returned from the DUT must be true.
9.	Device.IP.Interface.<WAN>.IPv6Address.<GUA_RA>.Autonomous	The value returned from the DUT must be true.
10.	Device.IP.Interface.<WAN>.IPv6Address.<GUA_RA>.StaticType	The DUT must return a value of Inapplicable for the parameter.
11.	Device.IP.Interface.<WAN>.IPv6Address.<GUA_RA>.ChildPrefixBits	The DUT must return a value of the empty string for the parameter.

## prplOS.1.6.9: IPv6 WAN Prefix Delegation

**Purpose:** Ensure that DUT properly reports the WAN IPv6 prefix delegation.

**Parameters:**

Device.IP.Interface.<WAN>.IPv6Prefix.<GUA_IAPD>.	
Enable	
Prefix	<IPv6 Address prefix>
Status	
Origin	
PreferredLifetime	
ValidLifetime	
PrefixStatus	
OnLink	
Autonomous	
StaticType	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.IP.Interface.<WAN>.IPv6Address.<GUA>.Enable	The value returned from the DUT must be true.
2.	Get the parameter Device.IP.Interface.<WAN>.IPv6Address.<GUA>.Status	The DUT must return a value of Enabled for the parameter.
3.	Get the parameter Device.IP.Interface.<WAN>.IPv6Address.<GUA>.Prefix	The DUT must return a value of IPv6 prefix address of the WAN interface for the parameter.

4.	Get the parameter Device.IP.Interface.<WAN>.IPv6Address.<GUA>.Origin	The DUT must return a value of PrefixDelegation for the parameter based on the configuration.
5.	Device.IP.Interface.<WAN>.IPv6Address.<GUA>.PreferredLifetime	The DUT must return a value equal to the time when it will expire based on the preferred lifetime supplied from DHCPv6 IA_PD.
6.	Device.IP.Interface.<WAN>.IPv6Address.<GUA>.ValidLifetime	The DUT must return a value equal to the time when it will expire based on the valid lifetime supplied from DHCPv6 IA_PD.
7.	Device.IP.Interface.<WAN>.IPv6Address.<GUA>.PrefixStatus	The value returned from the DUT must be Preferred.
8.	Device.IP.Interface.<WAN>.IPv6Address.<GUA>.OnLink	The value returned from the DUT must be false.
9.	Device.IP.Interface.<WAN>.IPv6Address.<GUA>.Autonomous	The value returned from the DUT must be false.
10.	Device.IP.Interface.<WAN>.IPv6Address.<GUA>.StaticType	The DUT must return a value of Inapplicable for the parameter.
11.	Device.IP.Interface.<WAN>.IPv6Address.<GUA>.ChildPrefixBits	The DUT must return a value of the empty string for the parameter.

## prplOS.1.6.10: IPv4 LAN Status

**Purpose:** Ensure that DUT properly reports the LAN IPv4 status.

**Parameters:**

Device.IP.Interface.<LAN>.	
Enable	
IPv4Enable	
Status	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.IP.Interface.<LAN>.Enable	The value returned from the DUT must be true.
2.	Get the parameter Device.IP.Interface.<LAN>.Status	The DUT must return a value of Up for the parameter.
3.	Get the parameter Device.IP.Interface.<LAN>.IPv4Enable	The value returned from the DUT must be true.

## prplOS.1.6.11: IPv6 LAN Status

**Purpose:** Ensure that DUT properly reports the WAN IPv6 status.

**Parameters:**

Device.IP.Interface.<LAN>.	
Enable	
IPv6Enable	
Status	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.IP.Interface.<LAN>.Enable	The value returned from the DUT must be true.
2.	Get the parameter Device.IP.Interface.<LAN>.Status	The DUT must return a value of Up for the parameter.
3.	Get the parameter Device.IP.Interface.<LAN>.IPv6Enable	The value returned from the DUT must be true.

## prplOS.1.6.12: IPv4 LAN Address

**Purpose:** Ensure that DUT properly reports the LAN IPv4 address.

**Parameters:**

Device.IP.Interface.<LAN>.IPv4Address.<LAN>.	
Enable	
IPAddress	
Status	
SubnetMask	
AddressingType	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.IP.Interface.<LAN>.IPv4Address.<LAN>.Enable	The value returned from the DUT must be true.
2.	Get the parameter Device.IP.Interface.<LAN>.IPv4Address.<LAN>.Status	The DUT must return a value of Enabled for the parameter.
3.	Get the parameter Device.IP.Interface.<LAN>.IPv4Address.<LAN>.IPAddress	The DUT must return a value of IPv4 address of the LAN interface for the parameter.
4.	Get the parameter Device.IP.Interface.<LAN>.IPv4Address.<LAN>.SubnetMask	The DUT must return a value of IPv4 subnet mask of the LAN interface for the parameter.
5.	Device.IP.Interface.<LAN>.IPv4Address.<LAN>.AddressingType	The DUT must return a value of Static for the parameter.

## prplOS.1.6.13: IPv6 Link Local LAN Address

**Purpose:** Ensure that DUT properly reports the LAN IPv6 link-local address.

**Parameters:**

Device.IP.Interface.<LAN>.IPv6Address.<LLA>.	
Enable	
IPAddress	<IPv6 Link Local Address>
IPAddressStatus	
Status	
Origin	
PreferredLifetime	
ValidLifetime	
Anycast	

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.IP.Interface.<LAN>.IPv6Address.<LLA>.Enable	The value returned from the DUT must be true.
2.	Get the parameter Device.IP.Interface.<LAN>.IPv6Address.<LLA>.Status	The DUT must return a value of Enabled for the parameter.
3.	Get the parameter Device.IP.Interface.<LAN>.IPv6Address.<LLA>.IPAddress	The DUT must return a value of IPv6 link local address of the LAN interface for the parameter.
4.	Get the parameter Device.IP.Interface.<LAN>.IPv6Address.<LLA>.IPAddressStatus	The DUT must return a value of Preferred for the parameter.

5.	Get the parameter Device.IP.Interface.<LAN>.IPv6Address.<LLA>.Origin	The DUT must return a value of AutoConfigured for the parameter.
6.	Device.IP.Interface.<LAN>.IPv6Address.<LLA>.PreferredLifetime	The DUT must return a value of 9999-12-31T23:59:59Z for the parameter.
7.	Device.IP.Interface.<LAN>.IPv6Address.<LLA>.ValidLifetime	The DUT must return a value of 9999-12-31T23:59:59Z for the parameter.
8.	Device.IP.Interface.<LAN>.IPv6Address.<LLA>.Anycast	The value returned from the DUT must be false.

## prplOS.1.6.14: IPv6 Global LAN Address

**Purpose:** Ensure that DUT properly reports the LAN IPv6 global address.

**Parameters:**

Device.IP.Interface.<LAN>.IPv6Address.<GUA>.	
Enable	
IPAddress	<IPv6 Global Unicast Address>
IPAddressStatus	
Status	
Origin	
PreferredLifetime	
ValidLifetime	
Anycast	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.IP.Interface.<LAN>.IPv6Address.<GUA>.Enable	The value returned from the DUT must be true.
2.	Get the parameter Device.IP.Interface.<LAN>.IPv6Address.<GUA>.Status	The DUT must return a value of Enabled for the parameter.
3.	Get the parameter Device.IP.Interface.<LAN>.IPv6Address.<GUA>.IPAddress	The DUT must return a value of IPv6 global address of the LAN interface for the parameter.
4.	Get the parameter Device.IP.Interface.<LAN>.IPv6Address.<GUA>.IPAddressStatus	The DUT must return a value of Preferred for the parameter.

5.	Get the parameter Device.IP.Interface.<LAN>.IPv6Address.<GUA>.Origin	The DUT must return a value of AutoConfigured for the parameter based on the configuration.
6.	Device.IP.Interface.<LAN>.IPv6Address.<GUA>.PreferredLifetime	The DUT must return a value equal to the time when it will expire based on the time supplied from DHCPv6.
7.	Device.IP.Interface.<LAN>.IPv6Address.<GUA>.ValidLifetime	The DUT must return a value equal to the time when it will expire based on the time supplied from DHCPv6.
8.	Device.IP.Interface.<LAN>.IPv6Address.<GUA>.Anycast	The value returned from the DUT must be false.

## prplOS.1.6.15: IPv6 LAN Prefix

**Purpose:** Ensure that DUT properly reports the LAN IPv6 Router Advertisement prefix.

**Parameters:**

Device.IP.Interface.<LAN>.IPv6Prefix.<GUA>.	
Enable	
Prefix	<IPv6 Address prefix>
Status	
Origin	
PreferredLifetime	
ValidLifetime	
PrefixStatus	
OnLink	
Autonomous	
StaticType	
ParentPrefix	

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.IP.Interface.<LAN>.IPv6Address.<GUA>.Enable	The value returned from the DUT must be true.
2.	Get the parameter Device.IP.Interface.<LAN>.IPv6Address.<GUA>.Status	The DUT must return a value of Enabled for the parameter.
3.	Get the parameter Device.IP.Interface.<LAN>.IPv6Address	The DUT must return a value of IPv6 prefix address from within the IA_PD

	ss.<GUA>.Prefix	range for the parameter.
4.	Get the parameter Device.IP.Interface.<LAN>.IPv6Address.<GUA>.Origin	The DUT must return a value of Child for the parameter.
5.	Device.IP.Interface.<LAN>.IPv6Address.<GUA_RA>.PreferredLifetime	The DUT must return a value equal to the time when it will expire based on the preferred lifetime supplied in the IA_PD.
6.	Device.IP.Interface.<LAN>.IPv6Address.<GUA_RA>.ValidLifetime	The DUT must return a value equal to the time when it will expire based on the preferred lifetime supplied in the IA_PD.
7.	Device.IP.Interface.<LAN>.IPv6Address.<GUA_RA>.PrefixStatus	The value returned from the DUT must be Preferred.
8.	Device.IP.Interface.<LAN>.IPv6Address.<GUA_RA>.OnLink	The value returned from the DUT must be true.
9.	Device.IP.Interface.<LAN>.IPv6Address.<GUA_RA>.Autonomous	The value returned from the DUT must be true.
10.	Device.IP.Interface.<LAN>.IPv6Address.<GUA_RA>.StaticType	The DUT must return a value of Child for the parameter.
11.	Get the parameter Device.IP.Interface.<LAN>.IPv6Address.<GUA_RA>.ParentPrefix	The value returned must be the path of the WAN IA_PD prefix.
12.	Transmit a Router Solicitation from Client-1.	The DUT transmits a Router Advertisement with values specified in the above steps.

### prplOS.1.6.16: IPv4 LAN Change Address

**Purpose:** Ensure that DUT properly applies changes to the IPv4 LAN address.

**Parameters:**

Device.IP.Interface.<LAN>.IPv4Address.<LAN>.	
IPAddress	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.IP.Interface.<LAN>.IPv4Address.<LAN>.IPAddress=10.10.10.1	
2.	Transmit ICMP Echo Request from Client-1 to 10.10.10.1.	The DUT must transmit an ICMP Echo Reply to Client-1.

## prplOS.1.6.17: IPv4 LAN SubnetMask

**Purpose:** Ensure that DUT properly applies changes to the IPv4 LAN subnet mask.

**Parameters:**

Device.IP.Interface.<LAN>.IPv4Address.<LAN>.	
SubnetMask	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.IP.Interface.<LAN>.IPv4Address.<LAN>.SubnetMask=255.0.0.0	
2.	Transmit ICMP Echo Request from Client-1 with source address of 192.0.2.1 to DUT LAN address.	The DUT must transmit an ICMP Echo Reply to Client-1.
3.	Transmit ICMP Echo Request from Client-1 with source address of 192.168.10.1 to DUT LAN address.	The DUT must transmit an ICMP Echo Reply to Client-1.

## prplOS.1.6.18: IPv6 ULA

**Purpose:** Ensure that DUT properly sets the IPv6 Unique Local Address.

**Parameters:**

Device.IP.Interface.<LAN>.IPv6Address.<ULA>.	
Enable	true
IPAddress	FD02:CAFE::1
Anycast	false

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Add a new Device.IP.Interface.<LAN>.IPv6Address.<ULA> object with the parameters specified.	
2.	Transmit ICMPv6 Echo Request from Client-1 to FD02:CAFE::1.	The DUT must transmit an ICMP Echo Reply to Client-1.

### prplOS.1.6.19: MTU Configuration

**Purpose:** Ensure that DUT properly sets the MTU configuration.

**Parameters:**

Device.IP.Interface.<LAN>.	
MaxMTUSize	1300

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Set the parameter Device.IP.Interface.<LAN>.MaxMTUSize=1300.	
2.	Transmit IPv6 UDP Traffic with size of 1500 from Client-1 to Host-1.	The DUT must transmit an ICMPv6 Packet Too Big message in response to UDP traffic.

### prplOS.1.6.20: IP Interface BytesSent

**Purpose:** Verify the statistics for IP.Interface.{i}.Stats.BytesSent are properly reported.

**Parameters:**

Device.IP.Interface.<LAN>.Stats.	
BytesSent	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.IP.Interface.<LAN>.Stats.BytesSent	The DUT returns the value of BytesSent.
2.	Transmit 500 bytes of data from Client-1 to Host-1.	Host-1 transmits an Echo Reply to Client-1.
3.	Get the parameter Device.IP.Interface.<LAN>.Stats.BytesSent	The DUT returns a value of BytesSent that is 500 bytes more than the value in Step 1.

## prplOS.1.6.21: IP Interface BytesReceived

**Purpose:** Verify that the statistics for IP.Interface.{i}.Stats.BytesReceived are properly reported.

**Parameters:**

Device.IP.Interface.<LAN>.Stats.	
BytesReceived	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Transmit traffic from Client-1 to Host-1.	The DUT must forward traffic from Client-1 to Host-1.
2.	Get the parameter Device.IP.Interface.<LAN>.Stats.BytesReceived	The DUT returns the value of BytesReceived.
3.	Transmit 500 bytes of data from Client-1 to Host-1.	
4.	Get the parameter Device.IP.Interface.<LAN>.Stats.BytesReceived	The DUT returns a value of BytesReceived that is 500 bytes more than the value in Step 1.

## prplOS.1.6.22: IP Interface PacketsSent

**Purpose:** Verify the statistics for IP.Interface.{i}.Stats.PacketsSent are properly reported.

**Parameters:**

Device.IP.Interface.<LAN>.Stats.	
PacketsSent	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.IP.Interface.<LAN>.Stats.PacketsSent	The DUT returns the value of PacketsSent
2.	Transmit 5 packets from Client-1 to Host-1.	Host-1 transmits a 5 Echo Replies to Client-1.
3.	Get the parameter Device.IP.Interface.<LAN>.Stats.PacketsSent	The DUT returns a value of PacketsSent that is 5 more than the value in Step 1.

## prplOS.1.6.23: IP Interface PacketsReceived

**Purpose:** Verify that the statistics for IP.Interface.{i}.Stats.PacketsReceived are properly reported.

**Parameters:**

Device.IP.Interface.<LAN>.Stats.	
PacketsReceived	

**Functionality Tags:** Core

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Transmit traffic from Client-1 to Host-1.	The DUT must forward traffic from Client-1 to Host-1.
2.	Get the parameter Device.IP.Interface.<LAN>.Stats.PacketsReceived	The DUT returns the value of PacketsReceived.
3.	Transmit 5 packets from Client-1 to Host-1.	
4.	Get the parameter Device.IP.Interface.<LAN>.Stats.PacketsReceived	The DUT returns a value of PacketsReceived that is 5 packets more than the value in Step 1.

## prplOS.1.6.24: IP Interface UnicastPacketsSent

**Purpose:** Verify the statistics for IP.Interface.{i}.Stats.UnicastPacketsSent are properly reported.

**Parameters:**

Device.IP.Interface.<LAN>.Stats.	
UnicastPacketsSent	

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Transmit traffic from Client-1 to Client-2.	The DUT must forward traffic from Client-1 to Client-2.
2.	Get the parameter Device.IP.Interface.<LAN>.Stats.UnicastPacketsSent	The DUT returns the value of UnicastPacketsSent
3.	Transmit 5 unicast packets from Client-1 to the DUT.	The DUT transmits unicast packets in response.
4.	Transmit 5 multicast packets from Client-1 to the DUT.	The DUT transmits multicast packets in response.
5.	Transmit 5 broadcast packets from Client-2 to the DUT.	The DUT transmits broadcast packets in response.
6.	Get the parameter Device.IP.Interface <LAN>.Stats.UnicastPacketsSent	The DUT returns a value of UnicastPacketsSent that is 5 packets more than the value in Step 1.

## prplOS.1.6.25: IP Interface UnicastPacketsReceived

**Purpose:** Verify that the statistics for IP.Interface.{i}.Stats.UnicastPacketsReceived are properly reported.

**Parameters:**

Device.IP.Interface.<LAN>.Stats.	
UnicastPacketsReceived	

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Device.IP.Interface.<LAN>.Stats.UnicastPacketsReceived	The DUT returns the value of UnicastPacketsReceived.
2.	Transmit 5 unicast packets from Client-1 to the DUT.	
3.	Transmit 5 multicast packets from Client-1 to the DUT.	
4.	Transmit 5 broadcast packets from Client-1 to the DUT.	
5.	Get the parameter Device.IP.Interface.<LAN>.Stats.UnicastPacketsReceived	The DUT returns a value of UnicastPacketsReceived that is 5 packets more than the value in Step 1.

## prplOS.1.6.26: IP Interface MulticastPacketsSent

**Purpose:** Verify the statistics for IP.Interface.{i}.Stats.MulticastPacketsSent are properly reported.

**Parameters:**

Device.IP.Interface.<LAN>.Stats.	
MulticastPacketsSent	

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Transmit traffic from Client-1 to Client-2.	The DUT must forward traffic from Client-1 to Client-2.
2.	Get the parameter Device.IP.Interface.<LAN>.Stats.MulticastPacketsSent	The DUT returns the value of MulticastPacketsSent
3.	Transmit 5 unicast packets from Client-1 to the DUT.	The DUT transmits unicast packets in response.
4.	Transmit 5 multicast packets from Client-1 to the DUT.	The DUT transmits multicast packets in response.
5.	Transmit 5 broadcast packets from Client-2 to the DUT.	The DUT transmits broadcast packets in response.
6.	Get the parameter Device.IP.Interface <LAN>.Stats.MulticastPacketsSent	The DUT returns a value of MulticastPacketsSent that is 5 packets more than the value in Step 1.

## prplOS.1.6.27: IP Interface MulticastPacketsReceived

**Purpose:** Verify that the statistics for IP.Interface.{i}.Stats.MulticastPacketsReceived are properly reported.

**Parameters:**

Device.IP.Interface.<LAN>.Stats.	
MultiPacketsReceived	

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Get the parameter Device.IP.Interface.<LAN>.Stats.Multi castPacketsReceived	The DUT returns the value of MulticastPacketsReceived.
2.	Transmit 5 unicast packets from Client-1 to the DUT.	
3.	Transmit 5 multicast packets from Client-1 to the DUT.	
4.	Transmit 5 broadcast packets from Client-1 to the DUT.	
5.	Get the parameter Get the parameter Device.IP.Interface.<LAN>.Stats.Multi PacketsReceived	The DUT returns a value of MulticastPacketsReceived that is 5 packets more than the value in Step 1.

## prplOS.1.6.28: IP Interface BroadcastPacketsSent

**Purpose:** Verify the statistics for IP.Interface.{i}.Stats.BroadcastPacketsSent are properly reported.

**Parameters:**

Device.IP.Interface.<LAN>.Stats.	
BroadPacketsSent	

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Transmit traffic from Client-1 to Client-2.	The DUT must forward traffic from Client-1 to Client-2.
2.	Get the parameter Device.IP.Interface.<LAN>.Stats.BroadcastPacketsSent	The DUT returns the value of BroadcastPacketsSent
3.	Transmit 5 unicast packets from Client-1 to the DUT.	The DUT transmits unicast packets in response.
4.	Transmit 5 multicast packets from Client-1 to the DUT.	The DUT transmits multicast packets in response.
5.	Transmit 5 broadcast packets from Client-2 to the DUT.	The DUT transmits broadcast packets in response.
6.	Get the parameter Device.IP.Interface <LAN>.Stats.BroadcastPacketsSent	The DUT returns a value of BroadcastPacketsSent that is 5 packets more than the value in Step 1.

## prplOS.1.6.29: IP Interface BroadcastPacketsReceived

**Purpose:** Verify that the statistics for IP.Interface.{i}.Stats.BroadcastPacketsReceived are properly reported.

**Parameters:**

Device.IP.Interface.<LAN>.Stats.	
MultiPacketsReceived	

**Functionality Tags:** Provisional Exclude

**Test Setup:** Common Test Setup is used at the beginning of each part.

**Procedure:**

Step	Action	Expected Behavior
1.	Get the parameter Get the parameter Device.IP.Interface.<LAN>.Stats.BroadcastPacketsReceived	The DUT returns the value of BroadPacketsReceived.
2.	Transmit 5 unicast packets from Client-1 to the DUT.	
3.	Transmit 5 multicast packets from Client-1 to the DUT.	
4.	Transmit 5 broadcast packets from Client-1 to the DUT.	
5.	Get the parameter Get the parameter Device.IP.Interface.<LAN>.Stats.BroadcastPacketsReceived	The DUT returns a value of BroadcastPacketsReceived that is 5 packets more than the value in Step 1.

## References

- [TR-181](#), Device Data Model, Broadband Forum
- [TR-069](#), CPE WAN Management Protocol, Broadband Forum
- [USP](#), User Services Platform, Broadband Forum